
# OPERATING INSTRUCTIONS AND PARTS LIST INSTRUCCIONES DE OPERACIÓN Y LISTA DE PIEZAS



## **ECONOLINE II**

For Models Equipped with 14", 18", AND 24" Blade Guards

This document supersedes all earlier versions of 0A7714.

# **TARGET**

17400 West 119<sup>th</sup> Street Olathe, Kansas 66061, USA

Customer Service	800-288-5040
Corporate. Office	
Customer Service FAX	
Corporate Office FAX	
International FAX	913-438-7938

Internet..... www.targetblue.com



EVERY MACHINE IS THOROUGHLY TESTED BEFORE LEAVING THE FACTORY. EACH MACHINE IS SUPPLIED WITH A COPY OF THIS MANUAL. OPERATORS OF THIS EQUIPMENT MUST READ AND BE FAMILIAR WITH THE SAFETY WARNINGS. FAILURE TO OBEY WARNINGS MAY RESULT IN INJURY OR DEATH. FOLLOW INSTRUCTIONS STRICTLY TO ENSURE LONG SERVICE IN NORMAL OPERATION.

### **CONTENTS**

Symbol Definitions	4 - 7
Decals - Descriptions and Locations	8 - 9
Saw Drive Configurations & Model Reference	
SAFETY WARNINGS - DO's & DO NOT's	
Reference Figures	
Pre-Operation Checklist / Maintenance	
Instructions:	
1 - Features	19
2 - Assembly	19
3 - Moving The Machine	
4 - Transport (Blade Removed)	
5 - Check Before Starting	20 - 21
6 - Fitting the Blade	
7 - Starting the Saw	21 - 22
8 - Stopping the Saw	
9 - Incidents During Sawing	
10 - Maintenance	23 - 24
11 - Blade Shaft V-Belt Tension	24
12 - Important Advise	
13 - Governor Speeds	
14 - Optional and Accessory Items	25
15 - Repairs	
16 - Spare Parts	26
Diagrams and Spare Parts	
Wiring Diagrams	

ANTES DE SALIR DE NUESTRA FÁBRICA, CADA MÁQUINA ES SOMETIDA A PUREBAS DETENIDAS. CADA MÁQUINA DE CORTE ES ENTREGADA CON UNA CIPIA DE ESTE MANUAL. LOS OPERARIOS DE ESTOS EQUIPOS DEBEN LEER Y FAMILIARIZARSE CON LAS INSTRUCCIONES DE SEGURIDAD. EL NO PRESTAR ATENCIÓN A ESTAS ADVERTENCIAS PUEDE OCASIONAR GRAVES LESIONE. SIGA ESTRICAMENTE NUESTRAS INSTRUCCIONES Y SU MÁQUINA LE VA A PRESTAR LARGOS AÑOS DE SERVICIO EN CONDICIONES NORMALES DE UTILIZACIÓN.

#### **CONTENIDO**

Definición De Los Símbolos	4 - 7
Calcomanías - Descripción y Localización	
Configuraciones de los mandos de la sierra y especificaciones de modelos	10,11,28,29
ADVERTENCIAS DE SEGURIDAD - HACER Y NO HACER	30 - 31
Figuras de referencia	32 - 33
Lista de revisiones previas a la operación / Mantemiento	34
Instrucciones:	
1 - Características	35
2 - Montaje	
3 - Transporte de la Máquina	
4 - Transporte (Sin la Hoja)	
5 - Revisiones Antes Del Arranque	
6 - Instalación de la Hoja	
7 - Arranque de la Sierra	
8 - Parada de la Sierra	
9 - Incidentes Durante El Aserrado	39
10 - Instrucciones De Mantenimiento	
11 - Tensión de La Correa En V Del Eje De La Hoja	
12 - Recomendación Importante	
13 - Velocidad Del Regulador	
14 - Items En Opción y Accesorios	
15 - Reparaciones	
16 - Piezas De Recambio	
Diagramas y Piezas De Recambio	
Diagramas De Cableado	

## Symbol Definitions Definición De Los Símbolos



- Please read the instructions for use prior to operating the machine for the first time.
- Antes de la puesta en marcha, lea detenidamente las instrucciones y familiarícese con la máquina.



- Mandatory
- Obligatorio



- Indication
- Indicación



- Prohibition
- · Prohibición



- Warning Triangle
- Triángulo De Advertencia



- · Wear Eye Protection
- · Usar Gafas De Protección



- · Wear Head Protection
- · Usar Casco De Protección



- · Wear Breathing Protection
- Usar Máscara De Protección



- The Use Of Ear Protection Is Mandatory
- Es Obligatorio El Uso De Protección Auditiva



- · Wear a Hard Hat
- · Usar Casco Duro



- · Wear Safety Shoes
- · Usar Zapatos De Seguridad



- Wear Appropriate Clothing
- · Usar Ropa Adecuada



- Remove The Blade Prior To Hoisting, Loading, Unloading And Transporting The Machine On Jobsite.
- Desmontar El Disco Antes De Desplazar, Cargar, Descargar O Transportar La Máquina En La Obra.



- Muffler Hot. May Cause Burns and / or Ignition Of Material. Avoid Contact.
- Silenciador de tubo de escape caliente. Puede causar quemaduras y/o ignición del material. Evite los contactos.



- · Motor Off
- · Parar El Motor



- · Use In Well Ventilated Area
- Usar En Una Área Bien Ventilada



- · Do Not Use In Flammable Areas
- No Usar In Áreas Inflamables



- · Machinery Hazard, Keep Hands And Feet Clear.
- Máquina Peligrosa Mantenga Manos Y Pies Alejados De La Máquina



- Danger, Poison Exhaust Gas
- Peligro, Gases De Escape Tóxicos



- · No Non-working Personnel In Area
- · Prohibido Para Personas Ajenas A La Obra



- No Smoking
- No Fumar



- · Do Not Operate Without All Guards In Place
- No Operar Sin Todas Las Protecciones In Su Sitio



- Always Keep the Blade Guards In Place
- Mantenga Siempre Las Protecciones De La Hoja En Su Sitio



- · Water Supply On.
- Suministro De Agua Conectado.



- · Water Supply Off
- Suministro De Agua Desconectado



- · Water Supply
- · Suministro De Agua



- · Water Safety Switch-Press to Reset if Water Supply Interrupted
- Si Se Ha Interrumpido El Suministro De Agua, Pulsar El Conmutador De Seguridad De Agua Para Reposicionarlo.



- Coolant Temperature
- · Temperatura Del Líquido Refrigerante



- Keep Work Area Clean/Well Lit, Remove All Safety Hazards
- Mantenga Limpio El Sitio De Trabajo/Bien Iluminado, Elimine Todos Los Riesgos De Seguridad



- · Dangerously High Noise Level
- · Nivel De Ruido Elevadamente Peligroso



- Pay Extreme Attention To The Care And Protection Of The Machine Before Starting Up
- Ponga Extrema Atención Al Cuidado Y Preparación De La Máquina Antes De Ponerla En Marcha



- · Remove Tools From Area and Machine
- Elimine Las Herramientas Del Área Y De La Máquina



- Oil Pressure
- · Presión De Aceite



- Oil Required
- Necesita Aceite



- · Dipstick, Maintain Proper Oil Level
- Varilla De Control, Mantenga El Nivel De Aceite Correcto



- · Lubrication Point
- Punto De Lubrication



- Unleaded Fuel Only
- · Solamente Combustible Sin Plomo



- Repairs Are To Be Done By An Authorized Dealer Only
- Las Reparaciones Deben Ser Efectuadas Únicamente Por Un Distribuidor Autorizado



- Headlight
- Luz De Cruce



- · Diamond Blade
- · Sierra Diamantada



- Blade Diameter
- Diámetro De La Hoja



- Blade Engagement
- · Acoplamiento De La Hoja



- Pulley Diameter
- Diámetro De La Correa



- · Number of Revolutions Per Minute, Rotational Speed
- N° De Revoluciones Por Minuto, Velocidad De Rotación



- Blade Flange Diameter
- · Diámetro De La Brida De La Hoja



- · Blade Cutting Depth
- · Profundidad De Corte De La Hoja



- · Machine Mass (lbs)
- Masa De La Máquina (lbs)



- · Positive Battery Terminal
- · Terminal Positivo De Batería



- Electric Motor
- · Motor eléctrico



- Engine
- Motor



- Engine Speed Revolutions/Minute
- Velocidad Del Motor En Revoluciones Por Minuto (RPM)



- · Engine Start
- Arranque Del Motor

## **WARNING**

**HEARING HAZARD** 

DURING NORMAL USE OF THIS MACHINE, OPERATOR MAY BE EXPOSED TO A NOISE LEVEL EQUAL OR SUPERIOR TO  $85\ dB\ (A)$ 

## **ADVERTENCIA**

**PELIGRO AUDITIVO** 

DURANTE EL USO NORMAL DE ESTA MAQUINA, EL OPERADOR PUEDE ESTAR EXPUESTO A UN NIVEL DE RUIDO EQUIVALENTE O SUPERIOR **85 dB (A)** 

# DECAL DESCRIPTIONS AND LOCATIONS DESCRIPCIÓN DE CALCOMANÍAS Y UBICACIONES



P/N 046457 Location: Above Cowl On Water Safety Switch



P/N 160004 Location: Inside Cowl


GREASE BEARINGS DAILY LAGER TÄGLICH FETTEN

DE LAGERS DAGELIJKS SMEREN GRAISSER LES ROULEMENTS CHAQUE JOUR ENGRASAR LOS RODAMIENTOS A DIARIO INGRASSARE I CUSCINETTI OGNI GIORNO

P/N 040570 Location: Top, Front Of Frame



P/N 163246 Location: Rear Of Frame



P/N 176242 Location: Top of Cowl



DO NOT CHANGE TO A
LARGER BLADE GUARD SIZE
WITHOUT CHANGING TO
PROPER BELT DRIVE, ENGINE
SPEED AND BLADE FLANGES.
FAILURE TO COMPLY COULD
RESULT IN DEATH OR
SEROIUS BODILY INJURY.
SEE OPERATOR'S MANUAL FOR
INSTRUCTIONS. IF YOU DO NOT
HAVE AN OPERATOR'S MANUAL,
CALL TOLL FREE 1-800-288-5040

P/N 046128 Decal, Warning Qty 1 Location: Blade Guard



P/N 167952 Location: Rear of Cowl



P/N 176223 Location: Rear of Cowl



P/N 176203 Location: Rear of Cowl

# DECAL DESCRIPTIONS AND LOCATIONS DESCRIPCIÓN DE CALCOMANÍAS Y UBICACIONES

# **TARGET**

P/N 187695
Decal, Target (1/2" Tall Letters)
Qty 1
Location: On Control Panel Decal,
LH Top Corner



# **TARGET**

## **ECONOLINE I**

P/N 187683 Decal, Target Econoline II Qty 2 Location: LH & RH Side Of Cowl



P/N 187697 Decal, Target TW-1.00 (1" Tall Letters) Qty 1 Location: Blade Guard (Black Paint)



P/N 190083

Decal, Diesel (After February 2001)


Qty 1 (Diesel Engine Models Only)

Location: Top of Cowl





P/N 189732
Decal, Target (1" Tall Letters)
Qty 1
Location: Rear Panel



P/N 187692 Decal, Control Panel, Mid-Range Saw Qty 1 Location: Top of Cowl

## Decals For Early Models (Before February 2001):



P/N 167129 Decal, Diesel Location: Top of Cowl Note: For Diesel Version Only, For Use With P/N 176186 Control Panel Decal.



P/N 176456 Decal Unleaded Fuel Only Location: Top of Cowl Note: For Gasoline Engine Models Only. For Use With P/N 176186 Control Panel Decal

## SPECIAL INSTRUCTIONS

#### FOR CHANGING BLADE SPEED ON CONCRETE / ASPHALT SAWS



WARNING: Do not exceed blade shaft speed shown for each blade size. Excessive blade

speed could result in blade breakage and serious personal injury.

**NOTE:** As shown on the chart, some blade guards accept more than one size blade.

## INSTRUCCIONES ESPECIALES

#### PARA CAMBIAR LA VELOCIDAD DE LA HOJA EN SIERRA PARA CONCRETO / ASFALTO



ADVERTENCIA: No exceder la velocidad del eje de la hoja indicada para cada tamaño de hoja. El

exceso de velocidad podría resultar en rotura de la hoja y graves lesiones

personales.

**NOTA:** Tal como se muestra en la tabla, algunos protectores de hojas aceptan más de un tamaño de hoja.

EC II

GASOLINE ENGINE SPEED / BLADE SIZE

VELOCIDAD DEL MOTOR DE GASOLINA / TAMAÑO DE LA HOJA

		BLADE	SHAFT	GASOLINE ENGINE			
		EJE	HOJA	MOTOF	MOTOR DE GASOLI		
	MODEL	LOADED	PULLEY	LOADED	PULLEY	MAXIMUM	
BLADE		RPM	SIZE	RPM	SIZE	RPM	
		CARGADO	TAMAÑO	CARGADO	TAMAÑO	RPM	
HOJA		RPM	POLEA	RPM	POLEA	MAXIMO	
	18W	2650	4.12 <b>"</b>	2800	3.65 <b>"</b>	3000	
14"	20KC	2620	4.12 <b>"</b>	3400	3.00"	3600	
20"	20H	2620	4.12 <b>"</b>	3400	3.00"	3600	
	24H	2620	4.12 <b>"</b>	3400	3.00"	3600	
	25KC	2620	4.12 <b>"</b>	3400	3.00"	3600	
	18W	N/A	N/A	N/A	N/A	N/A	
24"	20KC	1896	4.75 <b>"</b>	3400	2.65"	3600	
	20H	1896	4.75 <b>"</b>	3400	2.65"	3600	
	24H	1896	4.75 <b>"</b>	3400	2.65"	3600	
	25KC	1896	4.75 <b>"</b>	3400	2.65"	3600	

EC II

DIESEL ENGINE SPEED / BLADE SIZE


VELOCIDAD DEL MOTOR DE DIESEL/ TAMAÑO DE LA HOJA

				EL ENGINE OR DE DIESE	
MODEL	LOADED	PULLEY	LOADED	PULLEY	MAXIMUM
14"/ 20" Blade	RPM	SIZE	RPM	SIZE	RPM
	CARGADO	TAMAÑO	CARGADO	TAMAÑO	RPM
HOJA	RPM	POLEA	RPM	POLEA	MAXIMO
20D Hatz	2650	4.12 <b>"</b>	2800	3.65 <b>"</b>	3000

EC II - 15E
ELECTRIC MOTOR SPEED / BLADE SIZE
VELOCIDAD DEL MOTOR DE ELECTRICO / TAMAÑO DE LA HOJA

		SHAFT HOJA	ELECTRIC Motor de e	
MODEL	RATED	PULLEY	RATED	PULLEY
14"/ 20" Blade	RPM	SIZE	RPM	SIZE
	CARGADO	TAMAÑO	CARGADO	TAMAÑO
HOJA	RPM	POLEA	RPM	POLEA
15E	2510	4.12"	3450	3.00 <b>"</b>

# SAW DIMENSIONS [20" (500mm) Shown]



ITEM	DESCRIPTION	Inches	Metric
Α	Height to Pointer Up Position	46-3/8	117,8 cm
В	Minimum Saw Length	65	165,1 cm
	(Handles In, Pointer Up, Guard Up)		
С	Maximum Overall Length	94	238,8 cm
	(Handles Extended, Pointer Down)		
D	Saw Length, Handles Off, Guard Up	50	127 cm
E	Pointer Extension	29	73,7 cm
F	Frame Width	20	50,8 cm
G	Frame Length	38	96,5 cm
Н	Saw Width	27-3/4	70,5 cm
	Front Axle Length	17-3/4	45,1 cm
J	Rear Axle Length	17-3/4	45,1 cm
K	Blade to Wall	3-1/4	82,6 mm
L	Wheel Base Length	19	48,3 cm
M	Blade Shaft Maximum Height	12-1/4	31,1 cm
N	Height to Crank Handle	38	96,5 cm
0	Minimum Free Height (Rear)	1-3/4	4,5 mm
	Crated Dimension: (L x H x W)	57-1/2 x 33 x 49	146 x 83,8 x 124,5 cm

### **SAFETY FIRST!**



## WARNINGS DO's AND DO NOT's



# WARNING: FAILURE TO COMPLY WITH THESE WARNINGS AND OPERATING INSTRUCTIONS COULD RESULT IN DEATH OR SERIOUS BODILY INJURY.

DO

- DO Read this entire operator's manual before operating this machine. Understand all warnings, instructions, and controls.
- **DO** keep all guards in place and in good condition.
- **DO** wear safety approved hearing, eye, head and respiratory protection.
- **DO** read and understand all warnings and instructions on the machine.
- **DO** read and understand the symbol definitions contained in this manual.
- **DO** keep all parts of your body away from the blade and all other moving parts.
- **DO** know how to stop the machine quickly in case of emergency.
- **DO** shut off the engine and allow it to cool before refueling.
- **DO** turn the "ON/OFF" switch to the "OFF" position prior to connecting the machine to the power source.
- **DO** inspect the blade, flanges and shafts for damage before installing the blade.
- **DO** use the blade flange size shown for each blade size.
- **DO** use only steel center diamond blades manufactured for use on concrete saws.
- DO use only reinforced abrasive blades or steel center diamond blades manufactured for use on concrete saws.
- **DO** use only the blade flanges supplied with the saw. Never use damaged or worn blade flanges.
- **DO** use only blades marked with a maximum operating speed greater than the blade shaft speed. Verify speed by checking blade shaft rpm and pulley diameters and blade flange diameters.
- **DO** verify saw drive configuration by checking blade shaft RPM, pulley diameters, and blade flange diameter.
- DO read all safety materials and instructions that accompany any blade used with this machine.
- DO inspect each blade carefully before using it. If there are any signs of damage or unusual wear, DO NOT USE THE BLADE.
- **DO** mount the blade solidly and firmly, Wrench tighten the arbor nut.
- DO make sure the blade and flanges are clean and free of dirt and debris before mounting the blade on the saw.
- **DO** use the correct blade for the type of work being done. Check with blade manufacturer if you do not know if blade is correct.
- **DO** use caution and follow the instructions when loading and unloading the machine.
- **DO** operate this machine only in well ventilated areas.
- **DO** instruct bystanders on where to stand while the machine is in operation.
- **DO** establish a training program for all operators of this machine.
- DO clear the work area of unnecessary people. Never allow anyone to stand in front of or behind the blade while the engine is running.
- **DO** make sure the blade is not contacting anything before starting the engine.
- **DO** use caution when lifting and transporting this machine.
- **DO** always tie down the machine when transporting.
- **DO** use caution and follow instructions when setting up or transporting the machine.
- **DO** have all service performed by competent service personnel.
- DO make sure electric powered machines are plugged into a properly grounded circuit.
- **DO** make sure power cords are the proper size and in good condition.
- **DO** verify the blade arbor hole matches the machine spindle before mounting the blade.
- DO always check for buried electrical cables before sawing. If unsure, contact the local utilities.
- **DO** move the machine at least 10 feet (3 meters) from the fueling point before starting the engine and make sure the gas cap on the machine and the fuel can is properly tightened.
- **DO** lift only from the lift bail.
- **DO** clean the machine after each day's use.
- **DO** follow all electrical codes in your area.
- DO use correct voltage and proper extension cords. Never carry tool by cord or yank it to disconnect it from receptacle. Keep cord away from heat, oil and sharp edges.
- DO disconnect tools from power source when not in use, before servicing and when changing accessories.
- **DO** carefully maintain and clean for better and safer performance. Follow instructions for changing accessories. Inspect tool cords periodically and, if damaged, have repaired by authorized service facility.
- DO use the proper blade flange size for each blade size. Never use damaged or worn blade flanges.
- DO use caution when handling fuel.
- **DO** only cut in a straight line.
- **DO** only saw as deep as the job specifications require.
- DO always give a copy of this manual to the equipment user. If you need extra copies, call TOLL FREE 1-800-288-5040.

### **SAFETY FIRST!**



## WARNINGS DO's AND DO NOT's



# WARNING: FAILURE TO COMPLY WITH THESE WARNINGS AND OPERATING INSTRUCTIONS COULD RESULT IN DEATH OR SERIOUS BODILY INJURY.

#### DO NOT

DO NOT	operate this machine	unless you ha	ave read and u	inderstood this o	perator's manual

- **DO NOT** operate this machine without the blade guard, or other protective guards in place.
- **DO NOT** stand behind or in front of the blade path while the engine is running.
- **DO NOT** leave this machine unattended while the engine is running.
- **DO NOT** work on this machine while the engine is running.
- **DO NOT** operate this machine when you are tired or fatigued.
- **DO NOT** use a wet blade without adequate water supply to the blade.
- DO NOT exceed maximum blade speed shown for each blade size. Excessive speed could result in blade breakage.
- **DO NOT** operate the machine if you are uncertain of how to run the machine.
- **DO NOT** use damaged equipment or blades.
- **DO NOT** touch or try to stop a moving blade with your hand.
- **DO NOT** cock, jam, wedge or twist the blade in a cut.
- **DO NOT** transport a cutting machine with the blade mounted on the machine.
- **DO NOT** use a blade that has been dropped or damaged.
- **DO NOT** use carbide tipped blades.
- DO NOT use abrasive blades.
- **DO NOT** use conventional abrasive blades with water.
- DO NOT touch a dry cutting diamond blade immediately after use. These blades require several minutes to cool after each cut.
- **DO NOT** use damaged or worn blade flanges.
- **DO NOT** allow other persons to be near the machine when starting, refueling, or when the machine is in operation.
- **DO NOT** operate this machine in an enclosed area unless it is properly vented.
- **DO NOT** operate this machine in the vicinity of anything that is flammable. Sparks could cause a fire or an explosion.
- **DO NOT** allow blade exposure from the guard to be more than 180 degrees.
- **DO NOT** operate this machine while using drugs or alcohol.
- **DO NOT** operate this machine with the belt guard or blade guard removed.
- **DO NOT** operate this machine unless you are specifically trained to do so.
- **DO NOT** use a blade that has been over heated (Core has a bluish color).
- **DO NOT** jam material into the blade.
- **DO NOT** grind on the side of the blade.
- **DO NOT** lay power cords in or near the water.
- **DO NOT** tow this machine behind a vehicle.
- **DO NOT** leave the machine unattended with the motor running.
- **DO NOT** replace the motor with any motor that does not have a special grounding connection.
- **DO NOT** use the tie down brackets for lifting this machine.
- **DO NOT** operate this machine with the transmission guard removed.
- **DO NOT** cut deeper than 1" per pass with a dry blade. Step cut to achieve deeper cuts.

\*\*\*\*\*\*

This saw was designed for certain applications only. DO NOT modify this saw or use for any application other than for which is it was designed. If you have any questions relative to its application, DO NOT use the saw until you have written Diamant Boart, Inc. and we have advised you.

Diamant Boart, Inc. 17400 West 119th Street Olathe, Kansas 66061

## **EC II SPECIFICATIONS**

MODEL NO: 14"/20" Items Numbers: w/ Water Pump:	<b>18W</b> C20012 C20013	<b>20KC</b> C20020 C20021	<b>20H</b> C20069 C20070	<b>24H</b> C20076 C20077	<b>25KC</b> C20024 C20025	<b>20D</b> C20032 C20033	<b>15E</b> C20039
24" Items Numbers:	N/A	C20083	C20079	C20092	C20075	N/A	N/A
w/ Water Pump:	N/A	C20084	C20080	C20081	C20082	N/A	N/A
STANDARD SAV	<b>N FEAT</b>	<b>URES</b>					
Maximum Blade Guard		24"	24"	24"	24"		
Capacity:		(600mm)	(600mm)	(600mm)	(600mm)		
Bladeshaft RPM:	N/A	2008	2008	2008	2008	N/A	N/A
Max. Depth Of Cut:		9-1/2"	9-1/2"	9-1/2"	9-1/2"		
w/24" Blade		(24cm)	(24cm)	(24cm)	(24cm)		
Bladeshaft RPM:	N/A	2008	2008	2008	2008	N/A	N/A
Maximum Blade Guard	20"	20"	20"	20"	20"	20"	20"
Capacity:	(500mm)	(500mm)	(500mm)	(500mm)	(500mm)	(500mm)	(500mm)
Bladeshaft RPM:	2650	2620	2620	2620	2620	2650	2510
Max. Depth Of Cut:	7-1/2"	7-1/2"	7-1/2"	7-1/2"	7-1/2"	7-1/2"	7-1/2"
w/20" Blade	(19cm)	(19cm)	(19cm)	(19cm)	(19cm)	(19cm)	(19cm)
Max. Depth Of Cut:	4-1/2"	4-1/2"	4-1/2"	4-1/2"	4-1/2"	4-1/2"	4-1/2"
w/14" Blade	(11,4cm)	(11,4cm)	(11,4cm)	(11,4cm)	(11,4cm)	(11,4cm)	(11,4cm)
Bladeshaft RPM:	2650	2620	2620	2620	2620	2650	2510

**Arbor Size:** 1" with drive pin, blade can be mounted on either side of saw.

Blade Shaft: 1-3/16" diameter.

Blade Shaft Bearings: Dual self-aligning pillow block ball bearings.

Blade Shaft Drive: (4) premium 3VX V-belts

Blade Control: Raise / Lower with positive lock-type hand crank, screw feed with vertical grip.

Blade Coolant: Water; Dual water spray tubes; Water supply connector located on left side of saw; Control

valve on right side of cowl.

**Axles:** Front 1" Diameter; raises and lowers cutting head.

**Rear** 1" Diameter; drives wheels when transmission is engaged.

Wheels: Front 6" x 2" x 1"; roller bearings, solid rubber tires, neoprene grease seals, pressure

lubrication fittings provided.

Rear 8" x 3" x 1"; roller bearings, solid rubber tires, neoprene grease seals, pressure

lubrication fittings provided.

**Transmission:** Hydrostatic drive; direct V-belt drive from engine.

**Control** Quadco linear controller.

**Speed** Infinite speed 1 to 130 FPM, forward and reverse.

Chassis: Welded box section construction

Weight (lb.) Crated:	736	605	605	608	610	677	625
Uncrated:	691	560	560	563	565	632	580
Add for:							
Pump	10	10	10	10	10	10	10
Deluxe Spotlight	7	7	7	7	7	7	7
Weight Kit	26	26	26	26	26	26	26
Outer Flange Assy	5	5	5	5	5	5	5
Tie Down Bracket Kit	: 5	5	5	5	5	5	5

Specifications are subject to change without notice.

## **POWER SOURCE**

Engine:	<b>18W</b> Wisconsin Gas Engine	<b>20KC</b> Kohler Command Gas Engine	<b>20H</b> Honda Gas Engine	<b>24H</b> Honda Gas Engine	<b>25KC</b> Kohler Command Gas Engine	<b>20D</b> Hatz Diesel Engine
Specifications:	TJD	CH20S	GX620	GX670	CH25S	2G30
	Inline	V-Twin	V-Twin	V-Twin	V-Twin	Inline
	2-Cyl.	OHV	OHV	OHV	OHV	2-cyl.
Max. Horsepower:	18	20	20	24	25	20
Displacement: cu ii		38	37.5	40.9	44	55.65
(litres		(0.62)	(0.62)	(0.67)	(0.72)	(0.91)
Bore: inch	3.25	3.03	3.03	3.03	3.27	3.46
(mm)	(83)	(77)	(77)	(77)	(83)	(88)
Stroke: inch	3.25	2.64	2.60	2.83	2.64	2.24
(mm)	(83)	(67)	(66)	(72)	(67)	(57)
Cylinders / Stroke:	2/4	2/4	2/4	2/4	2/4	2/4
Fuel Capacity: gal	2.5	2.5	2.5	2.5	2.5	2.5
(litres)	(9.46)	(9.46)	(9.46)	(9.46)	(9.46)	(9.46)
Oil Capacity: pint	7	4	3	3	4.2	5.25
(litres)	(3.3)	(1.9)	(1.5)	(1.5)	(2.0)	(2.5)
Air Filter:	Oil	Dry Type,	Dry Type,	Dry Type,	Dry Type,	Oil
	Bath	Dual Element	Canister	Canister	Dual Element	Bath
Starter:	Electric	Electric	Electric	Electric	Electric	Electric
Coolant:	Air	Air	Air	Air	Air	Air

## **ELECTRIC MODELS:**


15E\*

Motor: Leeson Specifications: Electric Rated HP: 15 230-460 VAC Voltage: Phase: 3 Phase Cycles: 60 Hz. F.L. Amp Rating: 36/18 RPM: 3450 Frame Size: 215T

Specifications are subject to change without notice.

<sup>\*15</sup>E does not include power switch.

#### DIAGRAM 1



#### 1A RAISE / LOWER HAND WHEEL:


- **1B. WATER SAFETY SWITCH:** Stops the engine if the water supply to the blade is interrupted. Push to reset.
- 1C. WATER PUMP SWITCH:
- **1D. FUEL TANK FILL:** Fill the fuel tank at this location.
- **1E. ENGINE KEY SWITCH:** Start the engine using this switch.

#### 1F. DRIVE WHEEL ENGAGE LEVER:

**NEUTRAL POSITION:** The saw will stop travel movement when the speed control lever (1J) is in this position. The engine will not start unless the Speed Control Lever (1J) is in the NEUTRAL position.


- 1G. HOURMETER:
- 1H. HANDLE BARS: For operator gripping.
- **1I. KNOB:** Use to tighten operator grip handles.
- **1J. SPEED CONTROL LEVER:** Controls forward and reverse directions, stop, and the speed of the saw.
- **1K. BLADE DEPTH INDICATOR:** Displays cutting depth.
- **1L. BLADE DEPTH CONTROL LOCK:** Sets the depth stop for repetitive cuts at the same depth.

#### DIAGRAM 2



- **2A. BLADE SHAFT NUT:** Use to tighten the outer flange against the diamond blade.
- **2B. OUTER FLANGE:** Use to hold the diamond blade in position.
- 2C. NOT USED
- **2D. LOCKING PIN:** Use to prevent the diamond blade from rotating on the shaft during operation.
- **2E. DIAMOND BLADE:** Use as the cutting tool for concrete and asphalt surfaces.
- **2F. INNER FLANGE:** Inside support used to hold the diamond blade in position.
- **2G. BLADE GUARD NOSE LATCH:** Use to latch the front of the blade guard in the down position.
- **2H. BLADE GUARD FRONT:** The front section of the blade guard.
- **2I. BLADE SHAFT:** Supports the blade flanges and blade.

## DIAGRAM 3



- **3A. WATER VALVE:** Use to control the water supply to the diamond blade.
- **3B. LIFTING BAIL:** The saw can be lifted from this point.
- **3C. FRONT GUIDE:** Use to locate the path of the diamond blade on the cutting line.
- **3D. REAR GUIDE:** Use to locate the path of the diamond blade on the cutting line. (Not shown)

#### PRE OPERATION CHECKLIST



Before leaving our factory, every machine is thoroughly tested. Follow our instructions strictly and your machine will give you long service in normal operating conditions.



Before starting up the machine, make sure you read this entire operations manual and are familiar with the operation of the machine.

#### WITH MACHINE COLD AND SETTING LEVEL:

- 1. Check engine oil. Fill to full mark on dip stick with 10W30 oil. DO NOT OVERFILL!!
  - · Gas Models: Class MS, SD, SE or better.
  - · Diesel Models: Class CE or CD
- 2. Connect battery cables.
- 3. Electric Models: Verify all electrical connections are intact.

#### 1 - 2 HOUR OPERATION CHECK LIST:



ALWAYS park machine on a level surface with the engine "OFF" and the ignition switch set in the "OFF" position before performing any maintenance. Let the machine cool down!!

- 1. Check the engine air cleaner hose clamps. Tighten as required.
- 2. Tension the blade drive V-belts. DO NOT over tension!!
- 3. Check the transmission drive chain. DO NOT over tighten!!

#### SCHEDULED MAINTENANCE QUICK REFERENCE:



Before performing any maintenance, ALWAYS park the machine on a level surface with the engine "OFF" and the ignition switch set in the "OFF" position.

#### SERVICE DAILY:

- Check engine oil level.
- 2. Check blade guard for damage.
- Check hoses and clamps for damage. or looseness. Tighten or replace as necessary.
- 4. Lubricate bladeshaft bearings.
- 5. Lubricate front and rear wheel bearings.
- Check blade drive V-belt tension. DO NOT over tension!!! Change in sets only!

#### **SERVICE EVERY 50 HOURS:**

- 1. Replace engine oil and filter.
- 2. Clean engine/motor air fins.
- 3. Lubricate front axle pivot bearings.
- 4. Lubricate depth control adjustment screw.
- 5. Lubricate transmission drive shaft bearings.

#### **SERVICE EVERY 100 HOURS:**

- 1. Lubricate front axle pivot bearings.
- 2. Check wheels for wear or damage.
- 3. Check transmission drive chain and sprockets for looseness.
- 4. Check engine air cleaner hose and clamps.
- 5. Check hydrostatic transmission fluid level.

#### **SERVICE EVERY 500 HOURS:**

1. Replace hydrostatic transmission fluid

#### **SERVICE YEARLY:**

1. Replace air filter primary and safety elements.

NOTE: See engine manual for specific engine maintenance for your model.









These signs will give advice for your safety



Before leaving our factory every machine is thoroughly tested.

Follow our instructions strictly and your machine will give you long service in normal operating conditions.

## 1

#### **FEATURES**

**Use:** Wet sawing of old and new concrete and asphalt.

**Tools:** Diamond blades — water cooled, Ø: 10", 12", 14", 18", 20", and 24" with Arbor Ø- 1" (For information, contact your Target supplier)

CUTTING DEPTH					
Blade Size	Blade Depth (Maximum to Collar)	Maximum Depth (To Depth Stop)			
10" (250mm)	2-3/4" (68mm)	2-1/2" (62mm)			
12" (300mm)	3-3/4" (93mm)	3-1/2" (87mm)			
14" (350mm)	4-3/4" (118mm)	4-1/2" (112mm)			
18" (450mm)	6-3/4" (164mm)	6-1/2" (158mm)			
20" (500mm)	7-3/4" (197mm)	7-1/2" (190mm)			
24" (600mm)	8-3/4" (222mm)	8-1/2" (215mm)			



Before starting up the machine, make sure you read this entire manual and are familiar with the operation of this machine.



The working area must be completely clear, well lit and all safety hazards removed.



The operator must wear protective clothing appropriate to the work he is doing.





Any persons not involved in the work should leave the area.



Use only blades marked with a maximum operating speed greater than the blade shaft speed.

## 2

#### **ASSEMBLY**

- Attach the Handle Bars (1H) by inserting both Handles (1H) into the square holes, and then securely tighten the Knobs (1I).
- Attach Front Pointer assembly (3C) with capscrews.
   Tighten the hex nuts to prevent the capscrew from turning. Make sure the Pointer (3C) rotates freely.
- The 15 horsepower electric motor model (EC II-15E) DOES NOT INCLUDE POWER SWITCHES due to the wide range of switch specifications and local requirements.



WARNING: Power switches MUST BE provided by the purchaser so the EC II-15E will comply with all local and national electrical requirements. DO NOT use the EC II-15E without installing the proper power switches before operating the saw!

- The battery is shipped from the factory with the terminals wrapped in protective tape. The following steps MUST be taken to make the electrical starting system of the engine work.
  - 1. Remove the tape from the battery terminals and the battery cable ends.
  - 2. Connect the POSITIVE (+) red battery cable end to the POSITIVE (+) battery terminal. Tighten the capscrew and nut on the cable end securely to ensure proper electrical contacts.



WARNING: When tightening the POSITIVE (+) red battery cable end, DO NOT contact the NEGATIVE (-) battery terminal with the wrench or other metallic object. This could cause an electrical short circuit and ELECTRICAL SPARKING, OR AN EXPLOSION OF THE BATTERY!

3. Connect the NEGATIVE (-) black battery cable end to the NEGATIVE (-) battery terminal . Tighten the capscrew and nut on the cable end securely to ensure proper electrical contacts.

3

#### MOVING THE MACHINE

(See Figure 1 and 2)

#### Set The Handles To The Desired Length:

 Loosen Knob (1I), pull the Handle Bar (1H) in or out to desired length, then tighten the Knob (1I).

#### Moving The Saw With The Engine Off:

- Turn Engine Key Switch (1E) to the ON position.
- Raise the saw by cranking the Raise/Lower Hand Wheel (1A) COUNTERCLOCKWISE until the Diamond Blade (2E) (if installed) clears the pavement surface.
- Put the Speed Control Lever (1J) into the Neutral position.
- Engage the transmission.
- The saw can now be moved by standing behind it and pushing [while holding the Handle Bars (1H)].



DO NOT attempt to push the saw while it is parked on a grade (or hill). The saw operator could lose control of the saw and cause injury to himself or other person(s) in the area.

#### Moving The Saw With Engine On:

- Raise the saw by cranking the Raise/Lower Hand Wheel (1A) until the Diamond Blade (2E) (if installed) clears the pavement surface.
- Press the Water Safety Switch (1B) button. This will reset the Water Safety Switch, if the water supply has been interrupted.
- Push the transmission Engaging Lever (1F), located at rear center of cowl, DOWN to ENGAGE the transmission. Pull the Engaging Lever (1F) UP to DISENGAGE the transmission. When the engine is on and the saw is manually pushed, the transmission MUST be DISENGAGED.
- The transmission Speed Control Lever (1J) is located on the top, right hand side of the cowl. This lever controls the variable FORWARD and REVERSE ground speed (up to 130 feet per minute) of the saw.



WARNING: When engaging the transmission with the Engaging Lever, be sure the Speed Control Lever is at the NEUTRAL position to avoid saw movement.

 Turn the Engine Key Switch (1E) to the start position until the engine starts, then release the switch. It will return to RUN position. If the engine does not start, repeat these steps.



DO NOT attempt to start the saw while it is parked on a grade or hill.

 Put the Control Lever (1J) into gear. Push the Lever (1J) forward for Forward saw movement, or to the rear for Reverse saw movement. The further you push, the lever the faster the speed.



In an emergency to STOP ENGINE on the EC II-18W, PUSH and HOLD DOWN the KILL BUTTON (Figure 8, Item 3), located on the right-hand center of the saw cowl, until ALL

engine movement stops. For all other models, turn the KEY SWITCH to the OFF position and wait for ALL engine movement to stop.

4

### TRANSPORT (BLADE REMOVED)

(See Fig. 1, 2, and 3)



Turn Key Switch to "OFF" and wait for ALL engine movement to stop. Remove the Diamond Blade (2E) before transporting.



WARNING: All models are Self-Propelled. Use extreme caution and slow speed when using the self-propelling drive to move the saw up or down ramps or when loading or unloading from trucks or trailers.

When moving the saw up and down ramps, with engine running, use extreme caution.

- To go **DOWN** a ramp drive the saw **FORWARD** slowly.
- To go UP a ramp, back the saw in REVERSE slowly.

**Lifting The Saw.** The saw can only be lifted by the factory installed Lifting Bail (3B). **Do not use tie down brackets to lift the machine!!** 

#### To Transport By Vehicle:

- Set the Engine Key Switch (1E) in the OFF position.
- Set Speed Control Lever (1J) in the NEUTRAL position.
- Push Handle Bars (1H) inward and tighten Knobs (1I).



Block the saw in place or secure it into place to prevent movement during transport.

5

#### CHECK BEFORE STARTING













Take into account the working conditions from health and safety point of view.

- **Fuel:** Check the engine maintenance manual.
  - \* Gas Models: Unleaded gasoline is recommended.
  - Diesel Models: #2 Diesel fuel is recommended.
- Check that the engine oil level is correct. Because the engine often operates at an angle, check the oil level (with engine horizontal) frequently to ensure that the oil level never falls below the lower mark on the dipstick. 10W30 oil is recommended. **DO NOT OVERFILL!** See page 15 for capacity levels.

For start up, refer to the engine manual.



WARNING: ALWAYS DISENGAGE the self-propelling drive system BEFORE starting the engine.

6

#### FITTING THE BLADE

(See Fig. 1 and 2)



Always set the Engine Key Switch (1E) to the OFF position before mounting the blade.

- Set the Engine Key Switch (1E) to the OFF position.
- Raise the machine to a high position [by cranking the Raise/Lower Hand Wheel].
- Loosen the bolt on the Blade Guard Latch (2G).
- Raise the front half of the Blade Guard (2H).
- Unscrew the Blade Shaft Nut (2A). Remove Outer Flange (2B).
- Fit Diamond Blade (2E) on the Blade Shaft Arbor.
- Install Outer Flange (2B) into the Blade Shaft (2l) making sure that the Locking Pin (2D) passes through the Diamond Blade (2E) and into the Inner Flange (2F).

Note the direction of rotation of the blade. The direction of rotation is shown by an arrow on both the Diamond Blade (2E) and the Blade Guard (2H). Make sure that the contact surfaces on the Diamond Blade (2E), Inner & Outer Flanges (2B & 2F) and Blade Arbor are clean.

- Rotate Outer Flange (2B) and the Blade (2E) in the opposite direction of blade rotation to remove backlash.
- Install and tighten Blade Flange Nut using the Blade Shaft Wrench [50 lb.-ft. (68 N-m)] while firmly holding the Diamond Blade (2E).
- Lower front half of Blade Guard (2H) and tighten the Nut (2A) on the Blade Guard Latch (2G).



The Blade Shaft Nut (2A) on the Right Hand side has Left Hand threads.

#### STARTING THE SAW

(See Fig. 1, 2, and 3)



Always pay extreme care and attention to the preparation of the machine before starting.



Remove all wrenches and tools from the floor and the machine.



Always keep blade guard and transmission guard in place.

- Refer to the engine operating manual for proper engine operation and detailed information.
- Follow the operating instructions and warnings on top of the saw cowl.



WARNING: ALWAYS DISENGAGE the self-propelling drive system BEFORE starting the engine.

- Fill the fuel tank and check the engine oil level.
- Close the Water Valve (3A).
- Mark the surface to be cut by drawing a line where the cut is to be made.
- Loosen Knobs (1I), pull the Handle Bars (1H) in or out to desired length and tighten the Knobs (1I).
- Lower the Front Guide (3C). Align the Front Guide (3C), Rear Guide (3D) and the Diamond Blade (2E) with the line on the surface.
- To start the saw when no water pressure is present, push the reset button on the Water Safety Switch (1B).
- Start the engine using the Engine Key Switch (1E). Follow the procedure in the engine manual.
- Let the engine warm up at half throttle. All sawing is done at full throttle. The governor is factory set for the correct engine speed.
- When ready, open the Water Valve (3A) FULL open.



Test for adequate water supply [2-1/2 to 5 gal/min (10 to 20 lit./min)]. Low water flow will cause damage to diamond blades. If water supply is interrupted, stop cutting immediately.

See chart (Page 10) for the appropriate blade shaft and engine speeds for specific blade sizes.

 $\triangle$ 

WARNING: To STOP ENGINE on the EC II-18W, PUSH and HOLD DOWN the KILL BUTTON (Fig. 8 - Item 3), located on the right-hand center of the saw cowl, until ALL engine movement stops. For all other models, turn 'SWITCH (1E) to the OFF position and wait for

the KEY SWITCH (1E) to the OFF position and wait for ALL engine movement to stop.

Move the saw forward or reverse slowly by pushing or pulling on the Speed Control Lever (1J). Move the saw slowly to prevent stalling the blade. Make sure the Front Guide (3C), Rear Guide (3D) and the Diamond Blade (2E) stay on the line.

21

- Lower the blade into the cut by pulling up on the Depth Control Lock (1L) and by slowly turning the Hand Wheel (1A) assembly CLOCKWISE until the desired depth of cut is reached. Engage the Depth Control Lock (1L) to prevent the hand wheel from rotating.
- Push the transmission Engaging Lever (1F), located at rear center of cowl, DOWN to ENGAGE the transmission. Pull the Engaging Lever (1F) UP to DISENGAGE the transmission. When the engine is on and the saw is manually pushed, the transmission MUST be DISENGAGED.



WARNING: When engaging the transmission with the Engaging Lever, be sure the Speed Control Lever is at the NEUTRAL position to avoid saw movement.

- During cutting, DO NOT exert excessive side pressure on the Handle Bars (1H) to attempt to "STEER" the saw. Use only enough pressure to follow the previously marked line.
- If the saw should stall for any reason, raise the blade out of the cut, and DISENGAGE THE SELF-PROPELLING TRANSMISSION before restarting the engine!
- When lowering the blade into a partially made cut, the blade must be perfectly aligned within the cut before starting to saw again. DO NOT FORCE the blade into the material by lowering the blade too fast, or by propelling the saw too fast.

#### **Blade Cutting Depth Information:**

This saw is equipped with a Blade Depth Indicator (1K) which indicates the depth at which the Diamond Blade (2E) is cutting. This saw also includes a Blade Depth Control Lock (1L) which stops the cutting depth of the blade at a specified depth.

#### Use of the **BLADE DEPTH INDICATOR (1K)**:

- If the engine is running Turn the Engine Key Switch (1E) to the **OFF** position to **STOP** the engine.
- Lower the Diamond Blade (2E) by cranking the Raise Lower Hand Wheel (1A) CLOCKWISE until the Diamond Blade (2E) touches the surface to be cut.
- Set Blade Depth Indicator (1K) to "0" (zero).
- Lower the blade into the cut by pulling up on the Depth Control Lock (1L) and by slowly turning the Hand Wheel (1A) assembly CLOCKWISE until the desired depth of cut is reached. Engage the Depth Control Lock (1L) to prevent the hand wheel from rotating.

#### Use of the DEPTH CONTROL LOCK (1L):


- Lower the blade by pulling up on the Depth Control Lock (1L) and by slowly turning the Hand Wheel assembly (1A) CLOCKWISE until the Diamond Blade (2E) is at the required depth [as indicated on the Blade Depth Indicator (1K)].
- Engage the Depth Control Lock (1L) to prevent the hand wheel from rotating.



The saw WILL NOT lower to any depth greater than the position set on the Depth Control Lock (1L). Therefore, if a deeper cut is required, the Depth Control Lock (1L) MUST be loosened, then SET to the new depth required.

#### 8

#### STOPPING THE SAW



KEY SWITCH to the OFF position and wait for ALL engine movement to stop.

- Move the Speed Control Lever (1J) into the NEUTRAL position.
- Raise the blade out of the cut by pulling the Depth Control Lock (1L) upward, and turning the Hand Wheel (1A) COUNTERCLOCKWISE. Raise the blade high enough out of the cut to clear the pavement when maneuvering the saw.
- 3. Turn the Engine Throttle to the IDLE position.
- 4. Turn OFF the Water Valve (3A).
- 5. STOP the engine by turning the Engine Key Switch (1E) to the OFF position.



WARNING: When turning the saw OFF, be sure to turn the water pump OFF or the water pump will continue to run until the battery is dead!

#### 9

#### INCIDENTS DURING SAWING

(See Fig. 1 and 2)

If ENGINE STOPS while sawing, check the following:

Engine out of fuel—Check fuel level.



If the Diesel engine runs out of fuel, air must be removed from the fuel system before the engine will start. See diesel engine manual for detail air "bleeding" information.

- Lack of water signals the Water Safety Switch (1B) to stop the engine. Press button (1B) to reset the switch, and then restart the engine.
- Excessively fast cutting speed will stall engine.

If DIAMOND BLADE (2E) STOPS while sawing, check:

· Drive belt tension is inadequate.

#### If the ENGINE or BLADE STALLS for any reason.

 Raise the blade completely from the cut, inspect the machine thoroughly before restarting the engine. When lowering the blade into a partial cut, align the blade exactly with the cut to prevent damage to the blade.

#### 10

#### **MAINTENANCE INSTRUCTIONS**



Entrust all repairs to your authorized dealer only.



Before performing any maintenance, ALWAYS park the machine on a level surface with the Engine OFF and the Engine Start Switch in the OFF position.

After each use CLEAN the machine.

#### **LUBRICATION:**







**ENGINE OIL:** Check daily. Change engine Oil and Oil Filter after every 50 HOURS of operation. See engine manual for oil type to use. 10W30 is generally recommended.

\* Gas Models: 10W30 MS, SD, SE or better

\* Diesel Models: 10W30 CE or CD

Model: Capacity:
18W 7 pints
20KC 4 pints
20H-HDAC 3.2 pints
25KC 4.2 pints
20D - Hatz 5.25 pints

#### LUBRICATE BEARINGS DAILY:

- \* Front Wheels
- \* Rear Wheel
- Blade Shaft Bearings

#### BLADESHAFT BEARINGS:

- \* Lubricate daily with a Premium Lithium 12 based grease conforming to NLG1 GRADE #2 consistency, without Molybdenum Disulfide.
- \* When cutting dry, lubricate the blade shaft bearings 2 or 3 times daily. The grease provides an added protective seal for the bearings.

#### Replacement of Blade Shaft Bearings:

- A. Remove the blade shaft from the saw by removing the capscrews (Fig 2, Item 16).
- B. Remove the inner flanges (Fig 2, Item 18A) from the blade shaft using a hydraulic press or a similar press.
- C. Loosen the setscrews (Fig 2, Item15B) on the blade shaft bearing.
- D. Remove the bearings from the shaft. Replace with new bearings. Leave setscrews loose. Replace the inner flanges (Fig 2, Item 18A).
- E. Install the bladeshaft assembly back on the saw by replacing and tightening the capscrews.

- F. Align the blade shaft to the center of the frame, approximately 1-1/4" (32mm) from the side of the frame to the outside of the inner flange.
- G. Drill point the blade shaft at the setscrew locations.
- H. Install the setscrews with Loctite 272, and tighten.

#### **ENGINE CARE**

Refer to the engine manual for detailed information.

#### **CLEAN ENGINE AIR FILTER**

- Clean the air filter 2 or 3 times daily when dry cutting.
   DO NOT clean the Inner Safety Element!!!!! If present.
- Refer to the engine manual for detailed information.

#### DRIVEMATIC TRANSMISSION

A Hydrostatic Transmission ("DRIVEMATIC") (Fig 3, Item 6) makes this unit "SELF-PROPELLED." The saw can be pushed by simply disengaging the transmission.

#### **Maintenance of Transmission Drive:**

- Hydrostatic Transmission Oil:
   DAILY: Check the oil against the level indicator on the Oil Expansion Tank (Fig 3, Item 6A). Transmissions are factory filled with an oil having a viscosity equivalent to SAE20W20, API classification SE, CC, CD or better. When adding oil, use SAE 30W30, API classification SE, CC, CD or better. DO NOT use multiple viscosity oils! If erratic operation occurs during HOT WEATHER, drain oil and refill with an oil having a viscosity of SAE 30W30, or SAE 40W40, API classification SE, CC, CD or better. DO NOT OVERFILL!!
- Loose Drive Chain (Fig 3, Item 60)
   The drive chain will stretch during normal operation. It can be tightened by loosening the four (4) transmission attaching Bolts (Fig 3, Item 7), and moving the transmission UP in the slots of the Transmission Platform (Fig 3, Item 1).
- Friction Drive Wheels: (Fig. 3, Item 58) If the friction drive wheels DO NOT engage the rear wheels with sufficient pressure, slippage of the rear wheels may occur. To correct this situation, lengthen the Engagement Linkage (Fig. 3, Item 72) by loosening the two (2) linkage adjustment Bolts (Fig. 3, Item 73). Lengthen the linkage bars, and re-tighten the bolts.
- Hydrostatic Transmission Cooling Fins: (Fig 7, Item 6)
  DO NOT allow the cooling fins of the transmission to
  become covered, or clogged with dust or dirt. THIS
  WILL NOT ALLOW PROPER COOLING IN THE
  TRANSMISSION OIL!

#### **LIFT BAIL**

A standard Lift Bail (3B) is a factory installed item on all models. It is installed to achieve an optimum balance when lifting. Note the brace used (Fig 1, Item 81) with a given engine.



WARNING: Check that the Lift Bail (3B) mounting bolts are properly tightened [35 lb.-ft. (47 N-m) torque] to the frame and cowl! Check that the lifting bail and brace are mounted

in the proper position so that the saw DOES NOT tip to the front or rear when lifted. Check that the lifting bolts are tightened (Fig 1, Item 78) properly [70 lb.-ft. (95 Nm) torque].

#### HOUR METER

An Hour Meter (1G) is a factory installed item on all gas and diesel models. The Hour Meter (1G) will run continuously with the Key Switch (1E) in the ON position.

#### **DRIVE CHAIN AND SPROCKETS:**

Check for wear and looseness. Tighten as required.



Do not over tighten the Drive Chain!! The correct tightness allows for some slack.



11 |

Store in a safe place out of reach of children. Remove all adjustment tools and wrenches. Store diamond blade (2E) in a safe place so it cannot be damaged.

#### BLADE SHAFT V-BELT TENSION

This saw is equipped with high tension banded V-belts. The belts are properly tensioned at the factory but after a few hours of operation they will stretch and become loose.

#### To Tension V-Belts:

- Turn Engine Key Switch (1E) to the OFF position.
- Using the wrench, loosen the horizontal clamping bolts at the front of the engine base plate.
- Turn the Tensioning Bolt [at the front of engine base plate] CLOCKWISE until the V-Belts are tight.
- Replace V-Belts in complete sets only.



Never tension V-Belts beyond the original factory tension. Loose V-Belts result in poor saw performance and short belt life.

### 12 | IMPORTANT ADVISE

#### (See Fig. 2)

- Tighten loose nuts and bolts regularly, particularly after several hours of operation.
- Check V-Belt tension regularly. Re-tighten V-Belts as necessary. Replace V-Belts in complete sets only.
- Remove the Diamond Blade (2E) for storage. Store it carefully.
- Check the water spray over the Diamond Blade (2E) periodically.
- Tighten the Diamond Blade (2E) firmly on the Blade Arbor.
- Make sure the contact faces of Flanges (2B & 2F), Diamond Blade (2E), and Blade Shaft (2I) are clean.
- USE THE CORRECT DIAMOND OR ABRASIVE BLADE. For best performance, contact your TARGET distributor for the correct blade specification. The correct blade will make a tremendous difference in blade cost and performance.
- BEFORE MOUNTING THE BLADE (2E), inspect and clean the Blade Shaft Flange (2F) and Arbor. Inspect the Blade Arbor hole and Flange (2F) area for damage.
- Mount the blade firmly on the Blade Shaft Arbor. The Lock Pin in the Outer Blade Flange (2B) MUST go completely through the blade and into the matching hole on the Inside Blade Flange (2F). Tighten the Blade Flange Nut (2A) securely, approximately [50 lb.ft. (68 N-m)].



WARNING: DO NOT operate without the proper blade guard over the blade!



WARNING: DO NOT operate the saw with the front of the Blade Guard (2H) raised!!



WARNING: Blade exposure CANNOT exceed 180 degrees when operating!

 The Front Pointer (3C) and the Rear Pointer (3D) must be checked for alignment with the blade (2E). Both pointers (3C & 3D) must be in line with the blade mounted on the Blade Shaft (2I).



WATER FLOW from 2-1/2 to 5 gallons (10 to 20 liters) of water per minute MUST flow over the blade to properly cool it and to get maximum blade life. DO NOT use conventional (wet) diamond blades without water!

 For WET SAWING, be sure the water jets in the Blade Guard Water Tubes are open and that each side of the blade has an adequate supply of water. Test the water supply for pressure and quantity (flow) before starting to saw. If the water supply is interrupted, stop cutting immediately. The Water Safety Switch (1E) should shut down the engine.



NOTE: The Water Safety Switch (1E) cannot detect a clogged water line because it senses pressure, NOT flow.

 To start the saw when dry cutting, or when the water is not under pressure, push the reset button in the center of the Water Safety cut-off Switch (1E). Once the Switch is pushed in to reset, water pressure MUST be present to activate the safety shutdown.



NEVER run the water pump without water flowing through it.

- Saw only as deep as the specifications and job conditions require. Sawing excessively deep is wasteful

   avoid it! Step cut in increments of 2 inches (50 mm) for best results.
- Saw in a straight line. Mark the cutting line clearly so the saw operator can follow the line without difficulty. The saw should NOT be twisted from side to side trying to force the blade back on the line.

## 13

#### **GOVERNOR SPEEDS**

 It is critical that the governor and throttle on all internal combustion engines be adjusted properly. The engine speed is preset at the factory for the proper sawing speed. It is NOT normally necessary to change this setting. It should be periodically verified after the saw is placed into service. To change the governor setting, refer to the engine manual.



Serious injury can occur to the operator or people in the work area if the rotational speed (n/min) of the Diamond Blade (2E) exceeds the maximum speed (n/min) marked on the Diamond Blade (2E).

To ensure the proper governor adjustment, determine the correct blade shaft speed from the following chart. Follow the engine manufacturer's instruction procedure for the governor and throttle setting.

# NO LOAD BLADE SHAFT AND ENGINE RPMs

	BLADE SHAFT	ENGINE
MODEL	RPM	RPM
EC II-18W-14"/20"	2650	3000
EC II-20KC-14"/20"	2620	3600
EC II-20H-14"/20"	2620	3600
EC II-25KC-14"/20"	2620	3600
EC II-20D-14"/20"	2650	3000
EC II-15E-14"/20"	2510	3450
EC II-20H-24"	2008	3600
EC II-20KC-24"	2008	3600
EC II-25KC-24"	2008	3600

### 14

#### **OPTIONAL AND ACCESSORY ITEMS**

#### **ELECTRIC WATER PUMP (OPTIONAL)**

An optional Electric Water Pump is available for use on all gas and diesel engine models. READ and UNDERSTAND the operating instructions supplied with the pump (ITT-JABSCO, Model: 18510-Series).



WARNING: To be used to pump WATER ONLY! DO NOT pump other materials!

- This pump is NOT SELF-PRIMING, therefore it must be primed before operation. Sufficient Head Pressure (water source above the pump inlet) must be maintained for pump to operate.
- The water pump ON/OFF switch is located on the top of the cowl. This switch operates the water pump whether the engine is ON or OFF.



WARNING: Put the switch in the OFF position when done, or the water pump will continue to run until the battery is dead!

#### **WEIGHT KIT (P/N 176125)**

A weight kit is available as a field installed accessory. The weight kit bolts to the front of the saw frame using two (2) bolts, lockwashers, and nuts. Each weight bar weighs approximately 13 lbs. (.9 kg.). Two weight bars are supplied with each kit [26 lbs. (11.8 kg.) total weight]. NOTE: A weight kit may be necessary when sawing with a Kohler Command or Honda GX620 engine to keep the blade from rising out of the cut.

## SPECIAL OUTER FLANGE ASSEMBLY - 5/8" (16mm) WIDE CUT (P/N 176292)

 A Special Outer Flange Assembly is available as a field installed accessory. The special narrow outer flange allows the operator to stack blades up to 5/8" (16mm) wide. With the addition of a special narrow nut (Figure 2, Item 84), the operator can stack blades to 15/16" (23.8mm) wide.



WARNING: This special outer flange assembly is for use with blade width stacks of 3/8"-5/8" (10mm-16mm) only!

• If blade width stacks of less than 3/8" (10mm) are required, use the standard outer flange assembly supplied with the EC II. The Special Outer Flange Assembly can be identified by the COUNTERBORE on the "nut side" of the flange. The Standard Outer Flange Assembly has NO COUNTERBORE. The special narrow nut is for blade stack widths between 5/8"-15/16" (16mm-23.9mm).



WARNING: Failure to use proper flange and nut configurations WILL result in blade damage.

#### 15 | REPAIRS

We carry out all repairs in the shortest possible time and at the most economical prices. (See front page for our address and phone numbers.)

### 16 SPARE PARTS

For quick supply of spare parts and to avoid any lost time, it is essential to quote the data on the manufacture's plate fixed to the machine and the part number (s) to be replaced with every order.

The instructions for use and spare parts found in this document are for information only and are not binding. As part of our product quality improvement policy, we reserve the right to make any and all technical modifications without prior notice.



The manufacturer accepts no responsibility caused by unsuitable use or modifications

NOTE: NOTA:

## ESPECIFICACIONES EC II

NO. DE MODELO: 14"/ 20" Número De Ítem: 14"/20" Con Bomba De Agu: 24" Número De Ítem: 24" Con Bomba De Agu:	18W C20012 C20013 N/A N/A	20KC C20020 C20021 C20083 C20084	<b>20H</b> C20069 C20070 C20079 C20080	<b>24H</b> C20076 C20077 C20092 C20081	25KC C20024 C20025 C20075 C20082	20D C20032 C20033 N/A N/A	15E C20039  N/A N/A
<b>CARACTERISTICA</b>	S DE LA	SIERR	A ESTA	NDAR			
Capacidad Del Protector	N/A	24 pulg	24 pulg	24 pulg	24 pulg	N/A	N/A
De La Sierra:		(600mm)	(600mm)	(600mm)	(600mm)		
RPM Del Eje De La Hoja:	N/A	2008	2008	2008	2008	N/A	N/A
Profundidad Máx. De Corte:	N/A	9-1/2"	9-1/2"	9-1/2"	9-1/2"	N/A	N/A
(Con Hoja de 24")		(24cm)	(24cm)	(24cm)	(24cm)		
RPM Del Eje De La Hoja:	N/A	2008	2008	2008	2008	N/A	N/A
Capacidad Del Protector	20 pulg	20 pulg	20 pulg	20 pulg	20 pulg	20 pulg	20 pulg
De La Sierra:	(500mm)	(500mm)	(500mm)	(500mm)	(500mm)	(500mm)	(500mm)
RPM Del Eje De La Hoja:	2650	2620	2620	2620	2620	2650	2510
Profundidad Máx. De Corte:	7-1/2"	7-1/2"	7-1/2"	7-1/2"	7-1/2"	7-1/2"	7-1/2"
(Con Hoja de 20")	(19cm)	(19cm)	(19cm)	(19cm)	(19cm)	(19cm)	(19cm)
Profundidad Máx.De Corte:	4-1/2"	4-1/2"	4-1/2"	4-1/2"	4-1/2"	4-1/2"	4-1/2"
(Con Hoja de 14")	(11,4cm)	(11,4cm)	(11,4cm)	(11,4cm)	(11,4cm)	(11,4cm)	(11,4cm)

Tamaño Del Árbol: 1" con pasador impulsor, la hoja se puede instalar en cualquiera de los dos lados

2620

del eje (dos pasadores impulsores)

2620

Diámetro Del Eje De La Hoja: 1-3/16" diámetro

RPM Del Eje De La Hoja:

Cojinetes Del Eje De La Hoja: Cojinetes dobles de chumacera autoalineables

2650

Impulsor Del Eje De La Hoja: (4) correas trapezoidales 3VX

**Control De La Hoja:** Raise / Lower with positive lock-type hand crank, screw feed with vertical grip.

Refrigerante De La Hoja: Agua; Tubos dobles para rociar agua; conector de provisión de agua localizado en el

costado izquierdo de la sierra; válvula de control en el costado derecho de la estructura.

2620

2620

2650

2510

Ejes: Delantero 1" diámetro; eleva y desciende el cabezal de corte

Trasero 1" diámetro; impulsa las ruedas cuando la transmisión está engranada

**Ruedas:** Delanteras 6" x 2" x 1"; cojinetes de rodillo, ruedas de goma sólida, sellos de grasa de neoprene,

se proporcionan accesorios de lubricación a presión;

**Trasero** 8" x 3" x 1"; cojinetes de rodillo, ruedas de goma sólida, sellos de grasa de neoprene,

se proporcionan accesorios de lubricación a presión;

**Transmisión:** Impulsión hidrostática; impulsión directa de la correa en V del motor

Regulador Controlador lineal Quadco

Velocidad Infinita 1 a 130 rpm, avance y retroceso

Chasis: Construcción de la sección de la caja soldada

Peso Embalado	736	605	605	608	610	677	625
Desembalado:	691	560	560	563	565	632	580
Añadir Para: Bomba	10	10	10	10	10	10	10
Reflector de Lujo	7	7	7	7	7	7	7
Conjunto de Pasas	26	26	26	26	26	26	26
Conjunto de Brida Externa	5	5	5	5	5	5	5
Conjunto de Soportes	5	5	5	5	5	5	5
de Atadura							

Las especificaciones están sujetas a modificaciones sin previo aviso.

## **FUENTE DE ALIMENTACION**

Modelos: Motor:	<b>18W</b> Wisconsin Motor de gasolina	<b>20KC</b> Kohler Command Motor de gasolina	<b>20H</b> Honda Motor de gasolina	<b>24H</b> Honda Motor de gasolina	<b>25KC</b> Kohler Command Motor de gasolina	<b>20D</b> Hatz Diesel
Especificaciones:	TJD	CH20S	GX620	GX670	CH25S	2G30
	Inline	V-Twin	V-Twin	V-Twin	V-Twin	Inline
	2-Cyl.	OHV	OHV	OHV	OHV	2-cyl.
Potencia Máx.:	18	20	20	24	25	20
Cilindrada: cubic pulg	53.9	38	37.5	40.9	44	55.65
(Litros)	(0.88)	(0.62)	(0.62)	(0.67)	(0.72)	(0.91)
Diámetro : pulg	3.25	3.03	3.03	3.03	3.27	3.46
(mm)	(83)	(77)	(77)	(77)	(83)	(88)
Carrera: pulg	3.25	2.64	2.60	2.83	2.64	2.24
(mm)	(83)	(67)	(66)	(72)	(67)	(57)
Cilindros / Carrera:	2/4	2/4	2/4	2/4	2/4	2/4
Capacidad de Benzina:gal (litros)	2.5	2.5	2.5	2.5	2.5	2.5
	(9.46)	(9.46)	(9.46)	(9.46)	(9.46)	(9.46)
Capacidad de Aceite: pint (litros)	7	4	3	3	4.2	5.25
	(3.3)	(1.9)	(1.5)	(1.5)	(2.0)	(2.5)
Filtro de Aire:	Aceite Frasco de Baño	Tipo seco, Elemento Dualt	Tipo seco, Lata	Tipo seco, Lata	Tipo seco, Elemento Dual	Aceite Frasco de Baño
Arrancador:	Eléctrico	Eléctrico	Eléctrico	Eléctrico	Eléctrico	Eléctrico
Refrigerante:	Aire	Aire	Aire	Aire	Aire	Aire

### **MODELOS ELECTRICOS: 15E\***

Motor:LeesonEspecificaciones:EléctricoTasación del HP:15

Voltaje: 230-460 VAC
Fase: 3 Fases
Ciclos: 60 Hz.
Tasación F.L. del Amperaje: 36/18
Revoluciones por Minuto: 3450
Tamaño de la Estructura: 215T
Refrigerante: Aire

Las especificaciones están sujetas a modificaciones sin previo aviso.

<sup>\*</sup> El modelo 15E no incluye perilla de encendido.

## **iSEGURIDAD ANTE TODO!**



# **ADVERTENCIA:** EL NO RESPETAR ESTAS ADVERTENCIAS E INSTRUCCIONES DE OPERACION PUEDE PROVOCAR GRAVES LESIONES O LA MUERTE.

### **HACER**

- SI lea todo el manual antes de manejar esta máquina. Entienda todas las advertencias, instrucciones y controles.
- SI mantenga siempre las protecciones en su lugar y en buenas condiciones.
- SI siempre use protecciones aprobadas para los oídos, ojos, cabeza y respiración.
- SI lea y entienda todas las advertencias e instrucciones sobre la máquina.
- SI lea y entienda las definiciones de los símbolos que aparecen en este manual.
- SI mantenga todas las partes de su cuerpo alejadas de la hoja y de todas las piezas móviles
- SI aprenda cómo parar la máquina rápidamente en caso de emergencia.
- SI apague el motor y déjelo enfriar antes de cargar combustible.
- SI ponga el interrumpor en la posición OFF antes de corectarlo a la fuente de poda.
- SI verifique que la hoja, las bridas y los ejes no estén dañados antes de instalar la hoja.
- SI usar el tamaño de brida de hoja que se muestra para cada tamaño de hoja.
- SI use sólo discos diamantados con núcleo de acero fabricados específicamente para cortadoras de concreto.
- SI use sólo discos abrasivos reforzados o discos diamantados con núcleo de acero fabricados para cortadoras de concreto.
- SI usar el tamaño de brida de hoja que se muestra para cada tamaño de hoja.
- SI utilice hojas abrasivas, o bien, hojas diamantadas con centro de acero fabricadas para utilización en sierras para albañilería. Verifique la velocidad comprobando las rpm del eje de la hoja y el diámetro de las poleas.
- SI verifique la configuración del motor de la sierra, comprobando la velocidad (rpm) del eje de la hoja y los diámetros de las poleas.
- SI lea toda la literatura e instrucciones de seguridad que acompañan a la hoja utilizada con esta máquina.
- SI inspeccione cuidadosamente cada hoja antes de usarla. Si se observan señales de daño o desgaste poco común, NO USE LA HOJA.
- SI instale la hoja firmemente. Apriete la tuerca del eje con un aprietatuercas.
- SI asegúrese que la hoja y las bridas estén limpias y libres de tierra y suciedad antes de instalar la hoja en la sierra.
- SI utilice la hoja correcta para el tipo de trabajo que se vaya a ejecutar. En caso de dudas, consultar con el fabricante de la hoja.
- SI tenga cuidado y siga las instrucciones cuando cargue y descargue la máquina.
- SI maneje esta máquina solamente en lugares bien ventilados.
- SI Indique a las personas dónde situarse mientras la máquina está funcionando.
- SI establezca un programa de entrenamiento para todos los operadores de esta máquina.
- SI despeje el lugar de trabajo de personas innecesarias. No permita que nadie se sitúe delante o detrás de la hoja mientras el motor está funcionando.
- SI asegúrese que la hoja no esté haciendo contacto con ninguna cosa antes de arrancar el motor.
- SI tenga cuidado al levantar y transportar esta máquina.
- SI siempre amarre bien la máquina cuando la transporte.
- SI sea duidadoso y siga las intrucciones al instalar o transportar la máquina.
- SI deje que todos los trabajos de mantenimiento los haga personal especializado.
- SI asegúrese de enchufar las máquinas eléctricas a un circuito debidamente conectado a tierra.
- SI asegúrese que los cordones eléctricos sean del tamaño correcto y estén en buenas condiciones.
- SI antes de instalar la hoja, verifique que el aquiero del eje de la hoja coincida con el eje portaherramienta de la máquina.
- SI siempre buscar si hay cables eléctricos subterráneos antes de aserrar. En caso de dudas, llamar a la empresa de electricidad local.
- SI alejar la máquina por lo menos 3 metros (10pies) del punto de abastecimiento de combustible antes de poner en marcha el motor, y asegurarse que la tapa de combustible en la máquina a la tapa en la lata de combustible estén bien apretadas.
- SI levantar la máquina solamente del aro para izar.
- SI limpie la máquina diariamente.
- SI cumpla con el reglamento eléctrico de su localidad.
- SI tenga en cuenta el medio ambiente de la zona de trabajo. No exponga útiles eléctricos a la lluvia. no use útiles eléctricos en lugares húmedos.
- SI use el voltaje correcto y un cable de extensión adecuado. Nunca transporte la herramienta colgando del cable y nunca tire del cable para desenchufarlo. Aleje el cable del calor, aceite y de las aristas filudas.
- SI desenchufe los equipos cuando no los usa, antes de hacer mantenimiento y al cambiar accesorios.
- SI limpie y efectúe un mantenimiento cuidadoso para obtener un rendimiento mejor y más seguro. Siga las instrucciones al cambiar accesorios. Revise los cables del equipo con frecuencia y, si hay daños, hágalos reparar por un servicio autorizado.
- SI use el tamaño adecuado de hoja de brida para cada hoja. Nunca use hojas dañadas o desgastadas.
- SI use precaución cuando trabaja con combustibles.
- SI siempre aplique el freno de estacionamiento en cualquier máquina que no esté en uso.
- SI siempre ponga la transmisión a neutro antes de poner en movimiento la máquina.
- SI sólo corte en línea recta.
- SI sólo corte tan profundamente como las especificaciones del trabajo lo requieren.
- SI mantenga las manijas de la sierra de mano secas, limpias y libres de combustible o aceite.
- SI siempre entregar un ejemplar de este manual al usuario del equipo. Si se necesitan ejemplares adicionales, lammar SIN CARGO al 1-800-288-5040

## **iSEGURIDAD ANTE TODO!**



# **ADVERTENCIA:** EL NO RESPETAR ESTAS ADVERTENCIAS E INSTRUCCIONES DE OPERACION PUEDE PROVOCAR GRAVES LESIONES O LA MUERTE.

### **NO HACER**


- NO haga funcionar esta máquina sin antes haber leído y entendido este manual.
- NO maneje esta máquina sin tener la protección de la hoja u otras protecciones instaladas en su lugar.
- NO se sitúe detrás del paso de la hoja mientras el motor está funcionando.
- NO deje esta máquina desatendida mientras el motor está funcionando.
- NO trabaje en esta máquina mientras el motor está funcionando.
- NO maneje esta máquina si está cansado o fatigado.
- NO utilice una hoja de corte húmedo sin tener el suministro adecuado de agua.
- NO sobrepase la velocidad máxima indicada para cada tamaño de hoja. El exceso de velocidad puede causar la rotura de la hoja.
- NO trabaje con la máquina si tiene dudas sobre su funcionamiento u operación.
- NO utilice equipos u hojas que estén dañados.
- NO toque ni trate de parar con las manos una hoja en movimiento.
- NO incline, atasque, encaje o tuerza la hoja en el corte.
- NO transporte una máquina de corte con la hoja instalada.
- NO use un disco que haya sufrido un golpe o caída.
- **NO** use discos con puntas de carburo.
- NO use discos abrasivos.
- NO utilice discos abrasivos con agua convencionales.
- NO toque una hoja diamantada de corte en seco inmediatamente después de usarla. Estas hojas se demoran varios minutos en enfriarse después de cada corte.
- NO use bridas de hojas que estén dañadas o desgastadas.
- NO permita que nadie se acerque a la máquina durante la puesta en marcha o mientras la máquina está funcionando.
- NO maneje esta máquina en un lugar encerrado a menos que tenga buena ventilación.
- NO maneje esta máquina cerca de ningún objeto que sea inflamable. Las chispas podrían causar un incendio o una explosión.
- **NO** permita que la hoja sobresalga más de 180 grados del protector.
- NO maneje la sierra si está bajo la influencia de drogas o bebidas alcohólicas.
- NO maneje esta máquina sin el protector de la correa o de la hoja.
- NO maneje esta sierra sin estar capacitado para hacerlo.
- NO utilice una hoja que se ha sobrecalentado (el núcleo tiene un color azulado).
- NO atasque el material contra la hoja.
- NO esmerile con el costado de la hoja.
- NO deje los córdones eléctricos en o cerca del agua.
- NO remoclar esta máquina tirada por un vehículo.
- NO deje la máquina sola con el motor encendido.
- NO cambie el motor por alguno que no tenga una conexión especial de tierra de seguridad.
- NO usar las anillas de amarre para levantar esta máquina.
- NO manejar esta máquina sin que tenga puesto el protector de la transmisión.
- NO haga cortes más profundos a 1" por pasada con una hoja seca. Haga cortes intermitentes para cortes más profundos.

\*\*\*\*\*

Esta sierra fue diseñada para ciertas aplicaciones solamente. NO la modifique ni utilice para ninguna otra aplicación salvo aquéllas para las cuales fue diseñada. En caso de dudas respecto a su aplicación, NO use la sierra sin antes haber consultado por escrito a Diamant Boart, Inc. y haber recibido nuestras indicaciones.

Diamant Boart, Inc. 17400 West 119th Street Olathe, Kansas 66061

#### **ILUSTRACION 1**




- 1A. RUEDA MANUAL DE ELEVACION / DESCENSO:
- 1B. PERILLA DE SEGURIDAD DEL AGUA: Detiene el motor si se interrumpe la provisión de agua. Empújela para recomenzar.
- 1C. PERILLA DE LA BOMBA DE AGUA:
- **1D. LLENADO DEL TANQUE DE COMBUSTIBLE**: Llene el tanque de combustible en este lugar.
- **1E.** PERILLA DE PUESTA EN MARCHA DEL MOTOR: Accione el motor usando esta perilla.
- 1F. PALANCA DE ENGRANAJE DE LA TRANSMISION:
- 1G. MARCADOR DE HORAS:
- 1H. BARRAS DE SOPORTE: Para el control del operador.
- **11. BOTON:** Uselo para ajustar los soportes de control del operador.
- 1J. PALANCA DE CONTROL DE LA VELOCIDAD: Controla las direcciones hacia adelante y en reversa, la detención y la velocidad de la sierra. También cambia la transmisión de engranada a neutral.

**POSICION NEUTRAL:** La sierra detendrá la trayectoria del movimiento cuando la palanca de Control De La Velocidad (1J) esté en esta posición. El motor no se pondrá en marcha a menos que la Palanca De Control (1J) esté en la posición NEUTRAL.


- 1K. INDICADOR DE LA PROFUNDIDAD DE LA HOJA: Despliega la profundidad de corte.
- 1L. TRABA DEL CONTROL DE PROFUNDIDAD DE LA HOJA: Fija la profundidad de paro para cortes repetitivos a la misma profundidad.

#### **ILUSTRACION 2**



- **2A. PERNO DEL EJE DE LA HOJA:** Uselo para ajustar la brida externa contra la hoja diamantada.
- **2B. BRIDA EXTERNA:** Usela para mantener en posición a la hoja diamantada.
- 2C. NO USADO:
- **2D. CLAVIJA DE CIERRE:** Usela para prevenir que la hoja diamantada rote en el eje durante la operación.
- **2E. HOJA DIAMANTADA:** Usela como la herramienta de corte para superficies de concreto y asfalto.
- **2F. BRIDA INTERNA:** Apoyo interior usado para sostener a la hoja diamantada en posición.
- 2G. RETEN SALIENTE DEL PROTECTOR DE LA HOJA: Uselo para trabar el frente del protector de la hoja en la posición de abajo.
- **2H. FRENTE DEL PROTECTOR DE LA HOJA**: La sección frontal del protector de la hoja.
- **2I. EJE DE LA HOJA:** Soporta a las bridas de la hoja y a la hoja.

#### **ILUSTRACION 3**



- **3A. VALVULA DEL AGUA**: Usela para controlar la provisión de agua a la hoja diamantada.
- **3B.** BARRA PARA LEVANTAMIENTO: La sierra puede ser levantada desde este punto.
- **3C. GUIA FRONTAL:** Usela para localizar el camino de la hoja diamantada en la línea de corte.
- **3D. GUIA TRASERA:** Usela para localizar el camino de la hoja diamantada en la línea de corte. (No mostrado)

#### LISTA DE COMPROBACIONES PREVIAS A LA OPERACION



Antes de salir de la fábrica, todas las máquina son probadas extensivamente. Siga nuestras instrucciones al pie de la letra y su máquina le brindará muchos años de servicio en condiciones normales de trabajo.



Lea todo este manual y familiarícese con el funcionamiento de la máquina antes de ponerla en marcha.

#### CON LA MAQUINA FRIA Y NIVELADA:

- 1. Revisar el aceite del motor. Llenar hasta la marca "full" en la varilla de medición con aceite 10W30.
  - \* Modelos a gasolina: Clase MS, SD, SE o mejor.
  - Modelos diesel: Clase CE o CD
- Conectar los cables de la batería.
- 3. Modelos Eléctricos: Verificar que todas las conexiones eléctricas estén intactas.

#### LISTA DE REVISIONES DESPUES DE 1 A 2 HORAS DE FUNCIONAMIENTO:



SIEMPRE estacione la máquina en una superficie plana con el motor "APAGADO" y el interruptor de encendido puesto en la posición de DESCONECTADO antes de hacer ningún trabajo de mantenimiento. ¡Deje que la máquina se enfríe!

- 1. Verifique las pinzas de la manguera del limpiador de aire. Ajústelas tal como se requiere.
- 2. Tensione las correas en V de la transmisión de la hoja. NO las tensione en exceso.
- 3. Verifique la cadena impulsora de transmisión. ¡NO la apriete demasiado!

#### REFERENCIA RAPIDA DEL MANTENIMIENTO PROGRAMADO:



SIEMPRE estacione la máquina en una superficie plana con el motor "APAGADO" y el interruptor de encendido puesto en la posición de DESCONECTADO antes de hacer ningún trabajo de mantenimiento. ¡Deje que la máquina se enfríe!

#### MANTENIMIENTO DIARIO:

- 1. Revisar el nivel de aceite del motor.
- 2. Revisar la condición del protector de la hoja.
- Revisar las mangueras y abrazaderas en busca de daño o flojedad. Apretar o cambiar según sea necesario.
- 4. Lubricar los cojinetes del eje de la hoja.
- 5. Lubricar los cojinetes de las ruedas frontales y traseras.
- 6. Revisar la tensión de la correa trapezoidal impulsora de la hoja. Tensar el lado derecho e izquierdo uniformemente. ¡No tensar demasiado!

#### MANTENIMIENTO CADA 50 HORAS:

- 1. Cambiar el aceite y filtro del motor.
- 2. Limpiar el elemento del filtro de aire del radiador.
- 3. Lubricar los cojinetes de pivote del eje delantero.
- 4. Lubrique el tornillo de ajuste del control de la profundidad.
- 5. Lubrique los cojinetes del eje de la transmisión.

#### MANTENIMIENTO CADA 100 HORAS:

- 1. Lubricar los cojinetes de pivote del eje delantero.
- 2. Revisar las ruedas en busca de desgaste o daño.
- 3. Revisar la cadena impulsora y ruedas dentadas de la transmisión en busca de flojedad.
- Revisar la manguera y abrazaderas del filtro de aire del motor.
- 5. Revisar el nivel de fluido de la Transmisión Hidrostática.

#### MANTENIMIENTO CADA 500 HORAS:

1. Cambiar el fluido de la Transmisión Hidrostática.

#### MANTENIMIENTO ANUAL:

 Cambiar los elementos primario y secundario del filtro de aire.

NOTA: Vea el manual del motor para obtener información específica sobre el mantenimiento de su modelo de motor.



**OBLIGATORIO** 







**ADVERTENCIA** 



**PROHIBICION** 

Estos avisos le dan consejos para su seguridad



Antes de salir de la fábrica, todas las máquinas son probadas extensivamente.

Siga nuestras instrucciones al pie de la letra y su máquinale brindará muchos años de servicio en condiciones normales de trabajo.



#### **CARACTERISTICAS**

Uso: Aserrado en húmedo de hormigón y asfalto viejo o nuevo.

Herramientas: Hojas diamantadas - Enfriadas por agua, diám.: 250, 300, 350, 450, 500 y 600 mm; diámetro interior:

(Para información, contactar al proveedor de Target)

Profundidades de corte (maximas):					
Tamano del disco	Profundidad maxima de disco (hasta collar)	Profund.maxima (hasta tope)			
10" (250mm)	2-3/4" (68mm)	2-1/2" (62mm)			
12" (300mm)	3-3/4" (93mm)	3-1/2" (87mm)			
14" (350mm)	4-3/4" (118mm)	4-1/2" (112mm)			
18" (450mm)	6-3/4" (164mm)	6-1/2" (158mm)			
20" (500mm)	7-3/4" (197mm)	7-1/2" (190mm)			
24" (600mm)	8-3/4" (222mm)	8-1/2" (215mm)			



Antes de poner en marcha la máquina, asegúrese de leer todo este manual y familiarícese con el funcionamiento de esta máguina.



El lugar de trabajo debe estar totalmente despejado, bien iluminado y totalmente libre de riesgos para la seguridad.










El operador debe usar ropa protectora adecuada para el trabajo que está realizando.







Use solamente hojas marcadas con una velocidad máxima de funcionamiento mayor que la velocidad del eje de la hoja.

### **MONTAJE**

2

- Fije las Barras de Soporte (1H) insertando ambas Barras de Soporte (1H) dentro de los orificios cuadrados y luego apriete de manera segura las Perillas (11).
- Fije el conjunto de Apuntador Frontal (3C) con los tornillos de cabeza plana. Apriete las tuercas hexagonales para evitar que los tornillos giren. Asegúrese que el Apuntador (3C) rote libremente.
- El modelo de motor eléctrico de 15 caballos de fuerza (EC II-15E) NO INCLUYE PERILLAS DE ENCENDIDO debido a la amplia variedad de especificaciones para perillas y a los requisitos locales.



ADVERTENCIA: Las perillas de encendido DEBEN SER proporcionadas por el comprador demanera que el EC II-15E cumpla con todos los requisitos de electricidad locales y nacionales. ¡NO use el EC II-15E sin instalar las perillas de encendido apropiadas antes de hacer funcionar la sierra!

- 4. La batería es embarcada de la fábrica con las terminales envueltas en cinta protectora. Se DEBEN seguir los siguientes pasos para hacer que trabaje el sistema de encendido del motor.
  - A. Saque la cinta de las terminales de la batería y de los extremos del cable de la batería.
  - B. Conecte el extremo rojo POSITIVO (+) de la batería a la terminal POSITIVA (+) de la batería. Apriete de manera segura el tornillo de cabeza plana y la tuerca en el extremo del cable para asegurar que se cuente con contactos eléctricos apropiados.



ADVERTENCIA: Cuando apriete el extremo rojo POSITIVO (+) de la batería, NO ponga en contacto la terminal NEGATIVA (-) de la batería con una herramienta o con algún otro objeto de metal. ¡Esto podría producir un cortocicuito y una CHISPA ELECTRICA, O UNA **EXPLOSION DE LA BATERIA!** 

C. Conecte el extremo negro NEGATIVO (-) de la batería con la terminal NEGATIVA (-) de la batería. Apriete de manera segura el tornillo de cabeza plana y la tuerca en el extremo del cable para asegurar que se cuente con contactos eléctricos apropiados.

#### TRASLADO DE LA MÁQUINA

(Ver La Figuras 1 y 2)

#### Fije las Barras de Soporte a la Longitud

#### Deseada:

 Afloje la Perilla (11), estire la Barra de Soporte (1H) hacia adentro o hacia afuera hasta acanzar la longitud deseada, luego apriete la Perilla (11).

#### Movimiento de la Sierra con el Motor Apagado:

- Gire la Perilla de Llave del Motor (1E) a la posición de encendido (ON).
- Levante la sierra volteando la Rueda Manual de Elevación/Descenso (1A) en sentido ANTI-HORARIO hasta que la Hoja Diamantada (2E) (si está instalada) esté por encima de la superficie del pavimento.
- Ponga la Palanca de Control de la Velocidad (1J) en la posición Neutral.
- Engrane la transmisión.
- La sierra puede ser movida ahora parándose detrás de ella y empujándola [mientras se sostienen las Barras de Soporte (1H)].



NO intente empujar la sierra mientras que esté estacionada en una pendiente (o colina). El operador de la sierra podría perder el control de la sierra y producir lesiones a sí mismo o a otra(s) persona(s) presente(s) en esa área.

#### Movimiento de la Sierra con el Motor

#### **Encendido:**

- Levante la sierra volteando la Rueda Manual de Elevación/Descenso (1A) hasta que la Hoja Diamantada (2E) (si está instalada) esté por encima de la superficie del pavimento.
- Presione el botón de la Perilla de Seguridad del Agua (1B). Esto reposicionará la Perilla de Seguridad del Agua, si es que la provisión de agua ha sido interrumpida.
- Empuje la Palanca de Engranaje (1F) de la transmisión, localizada en la parte central posterior de la cubierta, hacia ABAJO para ENGRANAR la transmisión. Estire la Palanca de Engranaje (1F) hacia ARRIBA para DESENGRANAR la transmisión. Cuando el motor está encendido y la sierra es empujada manualmente, la transmisión DEBE ser DESENGRANADA.
- La Palanca de Control de la Velocidad (1J) de la transmisión está localizada en la parte superior, costado derecho de la cubierta. Esta palanca controla la velocidad de tierra variable HACIA ADELANTE y HACIA ATRAS (hasta 130 pies por minuto) de la sierra.



ADVERTENCIA: Cuando engrane la transmisión con la Palanca de Engranaje, asegúrese que la Palanca de Control esté en la posición NEUTRAL para evitar el movimiento de la sierra.

 Gire la Perilla de Llave del Motor (1E) a la posición de inicio hasta que se encienda el motor, luego suelte la perilla. Ella retornará a la posición de funcionamiento (RUN). Si el motor no se enciende, repita estos pasos.



NO intente arrancar la sierra mientras que ella esté estacionada en una pendiente o colina.

 Ponga la Palanca de Control (1J) en cambio. Empuje la Palanca (1J) hacia adelante para un movimiento hacia adelante de la sierra, o hacia atrás para movimiento en reversa de la sierra. Cuanto más lejos empuje la palanca, mayor será la velocidad.



En una emergencia para PARAR EL MOTOR en el EC II-18W, PRESIONE y MANTENGA APRETADO el BOTON DE PARO (Ilustración 8, Artículo 3), localizado en el costado derecho

central de la cubierta de la sierra, hasta que pare TODO movimiento de la sierra. Para todos los otros modelos,

### 4

#### TRANSPORTE (SIN LA HOJA)

(Ver Las Figuras 1, 2, y 3)



Gire la Perilla de Llave a la posición de apagado (OFF) y espere hasta que pare todo movimiento del motor. Saque la Hoja Diamantada (2E) antes del transporte.



ADVERTENCIA: Todos los modelos son autopropulsados. Sea extremadamente cuidadoso y use una velocidad lenta cuando utilice la transmisión auto-propulsada para mover la

sierra hacia arriba o hacia abajo de rampas o cuando la cargue o descargue de camiones o de remolques.

Cuando mueva la sierra hacia arriba o hacia abajo de rampas, con el motor en marcha, sea extremadamente precavido.

- Para ir HACIA ABAJO de una rampa, maneje la sierra lentamente HACIA ADELANTE.
- Para ir HACIA ARRIBA de una rampa, maneje la sierra lentamente HACIA ATRAS.

ILevantamiento de la Sierra. La sierra puede ser levantada solamente por medio de la Barra para Elevación (3B). ¡No use los soportes de atadura para levantar la máquina!

#### Para el transporte en vehículos:

- Fije la Perilla de Llave del Motor (1E) en la posición de apagado (OFF).
- Fije la Palanca de Control de la Velocidad (1J) en la posición NEUTRAL.
- Empuje las Barras de Soporte (1H) hacia adentro y apriete las Perillas (1I).



Bloquee la sierra en su lugar para evitar su movimiento durante el transporte.

5

### REVISIONES ANTES DEL ARRANQUE













Tenga en cuenta las condiciones de trabajo desde el punto de vista de la salud y seguridad.

- Gasolina o Diesel: Verifique el manual de mantenimiento del motor.
  - \* Modelos a Gasolina: Se recomienda el uso de gasolina sin plomo.
  - \* Modelos a Diesel: Se recomienda el uso de Diesel No. 2.
- Verifique que el nivel de aceite del motor sea el adecuado. Puesto que el motor funciona a menudo en ángulo, verifique frecuentemente el nivel del aceite (con el motor en forma horizontal) para asegurar que el nivel del aceite nunca descienda por debajo de la marca inferior en el indicador de aceite. Se recomienda el aceite 10W30. ¡NO LLENE POR DEMAS! Ver los niveles de capacidad en la página 29.
- Para el arranque, refiérase al manual del motor..



ADVERTENCIA: SIEMPRE DESENGRANE el sistema de auto-propulsión ANTES de arrancar el motor.

6

### **INSTALACIÓN DE LA HOJA**

(Ver Las Figuras 1 y 2)



Siempre fije la Perilla de Llave del Motor (1E) en la posición de apagado (OFF) antes de montar la hoja.

- Fije la Perilla de Llave del Motor (1E) en la posición de apagado (OFF).
- Levante la máquina a una posición elevada [volteando la Rueda manual de Elevación/Descenso].
- Afloje la tuerca en el Retén del Protector (2G).
- Levante la mitad frontal del Protector de la Hoja (2H).
- Desatornille la Tuerca del Eje de la Hoja (2A). Saque la Brida Externa (2B).
- Fije la Hoja Diamantada (2E) en el Arbol del Eje de la Hoja.
- Instale la Brida Externa (2B) dentro del Eje de la Hoja (2I), asegurando que la Clavija de Cierre (2D) pase a través de la Hoja Diamantada (2E) y dentro de la Brida Interna (2F).



Note la dirección de rotación de la hoja. La dirección de rotación se muestra por medio de una flecha tanto en la Hoja Diamantada (2E) como en el Protector de la Hoja (2H). Asegúrese que las superficies de contacto en la Hoja Diamantada (2E), las Bridas Internas y Externas (2B y 2F) y el Arbol de la Hoja estén limpios.

- Rote la Brida Externa (2B) y la Hoja (2E) en la dirección opuesta a la rotación de la hoja para sacar la contrapresión.
- Instale y ajuste la Tuerca de la Brida de la Hoja usando la Llave para el Eje de la Hoja [50 libras-pie (68 N-m)] mientras sostiene firmemente la Hoja Diamantada (2E).
- Descienda la mitad frontal del Protector de la Hoja (2H) y apriete la Tuerca (2A) en el Retén del Protector de la Hoja (2G).



La Tuerca del Eje de la Hoja (2A) en el costado Derecho tiene muescas a la Izquierda.

7

### ARRANQUE DE LA SIERRA

(Ver Las Figuras 1, 2 y 3)



Siempre preste mucho cuidado y atención a la preparación de la máquina antes de arrancarla.



Saque todas las llaves y herramientas del piso y de la máquina.



Siempre mantenga en su lugar el protector de la hoja y el protector de la transmisión.

- Refiérase al manual de operación del motor para obtener información detallada sobre la apropiada operación del motor.
- Respetar las instrucciones de operación y las advertencias que se encuentran encima de la cubierta de la sierra.



ADVERTENCIA: SIEMPRE DESENGRANE el sistema de auto-propulsión ANTES de arrancar el motor

- Llene el tanque de combustible y verifique el nivel del aceite del motor.
- Cierre la Válvula de Agua (3A).
- Marque la superficie a ser cortada dibujando una línea donde se realizará el corte.
- Afloje las Perillas (1I), estire las Barras de Soporte (1H) hacia adentro o hacia afuera hasta alcanzar la longitud deseada y apriete las Perillas (1I).
- Descienda la Guía Frontal (3C). Alinee la Guía Frontal (3C), la Guía Trasera (3D) y la Hoja Diamantada (2E) con la línea que está en la superficie.
- Para arrancar la sierra cuando no hay presente ninguna presión del agua, apriete el botón de reposicionamiento en la Perilla de Seguridad del Agua (1B).
- Arranque el motor usando la Perilla de Llave del Motor (1E). Siga el procedimiento descrito en el manual del motor.
- Deje que el motor se caliente con el obturador a la mitad.
   Todo corte es efectuado con el obturador al 100%. El regulador está fijado en fábrica para la correcta velocidad del motor.

 Cuando está listo, abra COMPLETAMENTE la Válvula del Agua (3A).



Compruebe que haya una adecuada provisión de agua [2-1/2 a 5 galones/minuto (10 a 20 litros/minuto)]. El bajo flujo de agua causará daños a las hojas diamantadas. Si se

interrumpe la provisión de agua, pare de cortar inmediatamente.



Vea el cuadro (Página 10) para determinar las velocidades apropiadas del eje de la hoja y del motor para tamaños específicos de la hoja.

ADVERTENCIA: Para PARAR EL MOTOR en el EC II-18W, PRESIONE y MANTENGA APRETADO el BOTON DE PARO (Ilustración 8 - Artículo 3), localizado en el costado central derecho de la cubierta de la sierra, hasta que se detengan TODOS los movimientos de la sierra. Para todos los otros modelos, gire la PERILLA DE LLAVE (1E) a la posición de apagado (OFF) y espere hasta que se detengan TODOS los movimientos de la sierra.

- Mueva la sierra lentamente haia adelante o hacia atrás, empujando o estirando la Palanca de Control de la Velocidad (1J). Mueva lentamente la sierra para evitar que se trabe la hoja. Asegúrese que la Guía Frontal (3C), la Guía Trasera (3D) y la Hoja Diamantada (2E) permanezcan en la línea.
- Descienda la hoja en el corte, estirando la Traba de Control de la Profundidad (1L) y girando lentamente el conjunto de la Rueda Manual (1A) en sentido HORARIO hasta que se alcance la profundidad de corte deseada. Engrane la Traba de Control de la Profundidad (1L) para evitar la rotación de la rueda manual.
- Presione la Palanca de Engranaje (1F), localizada en la parte posterior central de la cubierta, HACIA ABAJO para ENGRANAR la transmisión. Estire la Palanca de Engranaje (1F) HACIA ARRIBA para DESENGRANAR la transmisión. Cuando el motor está encendido y se empuja manualmente la sierra, la transmisión DEBE ser DESENGRANADA.



ADVERTENCIA: Cuando engrane la transmisión con la Palanca de Engranaje, asegúrese que la Palanca de Control de la Velocidad esté en la posición NEUTRAL para evitar el movimiento de la sierra.

- Durante el corte, NO aplique excesiva presión lateral en las Barras de Soporte (1H) para intentar "TIMONEAR" la sierra. Use solamente suficiente presión para seguir la línea marcada previamente.
- Si la sierra se traba por alguna razón, ¡levante la hoja fuera del corte y DESENGRANE LA TRANSMISION AUTO-PROPULSADA antes de volver arrancar el motor!
- Cuando descienda la hoja dentro de un corte parcialmente hecho, la hoja debe estar perfectamente alineada dentro del corte antes de arrancar nuevamente la sierra. NO FUERCE la hoja dentro del material, descendiéndola demasiado rápido ni propulsando la sierra demasiado rápido.

# Información sobre la Profundidad de Corte de la Hoia:

Esta sierra está equipada con un Indicador de Profundidad de la Hoja (1K) que indica la profundidad a la que está cortando la Sierra Diamantada (2E). Esta sierra también incluye una Traba de Control de la Profundidad de la Hoja (1L) que detiene la profundidad de corte de la hoja a una profundidad especificada.

# Uso del INDICADOR DE PROFUNDIDAD DE LA HOJA (1K):

- Si el motor está en funcionamiento Gire la Perilla de Llave del Motor (1E) a la posición de apagado (OFF) para PARAR la máquina.
- Descienda la Hoja Diamantada (2E) volteando la Rueda Manual de Elevación/Descenso (1A) en sentido HORARIO hasta que la Hoja Diamantada (2E) toque la superficie a ser cortada.
- Fije el Indicador de Profundidad de la Hoja (1K) en "0" (cero).
- Descienda la hoja dentro del corte, estirando la Traba de Control de la Profundidad (1L) y girando lentamente el conjunto de la Rueda Manual (1A) en sentido HORARIO hasta alcanzar la profundidad de corte deseada. Accione la Traba de Control de la Profundidad (1L) para evitar que la rueda manual rote.

# Uso de la **TRABA DE CONTROL DE LA PROFUNDIDAD** (1L):

- Descienda la hoja estirando la Traba de Control de la Profundidad (1L) y girando lentamente el conjunto de la Rueda Manual (1A) en sentido HORARIO hasta que la Hoja Diamantada (2E) esté a la profundidad de corte deseada [tal como se indica en el Indicador de la Profundidad de Corte (1K)].
- Accione la Traba de Control de la Profundidad (1L) para evitar que la rueda manual rote.



La sierra NO descenderá a una profundidad mayor que la posición fijada en la Traba de Control de la Profundidad (1L). De ahí que, si se requiere una mayor profundidad de corte, la

Traba de Control de la Profundidad (1L) DEBE ser aflojada, luego FIJADA a la nueva profundidad requerida.

sierra.

**MANTENIMIENTO** 

En una emergencia para PARAR EL MOTOR en el EC II-18W, PRESIONE y MANTENGA APRETADO el BOTON DE PARO (Ilustración 8, Artículo 3), localizado en el costado derecho central de la cubierta de la sierra, hasta que pare TODO movimiento de la sierra. Para todos los otros modelos, gire la PERILLA DE LLAVE a la posición de apagado (OFF) y espere hasta que pare TODO movimiento de la

- Mueva la Palanca de Control de la Velocidad (1J) a la posición NEUTRAL.
- Levante la sierra fuera del corte, estirando la Traba de Control de la Profundidad (1L) hacia arriba y girando la Rueda Manual (1A) en sentido ANTI-HORARIO. Levante la hoja lo suficientemente alto fuera del corte para separarla del pavimento cuando se maniobre la sierra.
- Gire el Obturador del Motor a la posición EN VACIO.
- Cierre la Válvula del Agua (3A).
- PARE la máquina girando la Perilla de Llave del Motor (1E) a la posición de apagado (OFF).



ADVERTENCIA: ¡Cuando apague la sierra, asegúrese de apagar la bomba de agua o la bomba continuará funcionando hasta que se acabe la batería!

9

### INCIDENTES DURANTE EL ASERRADO

(Ver Las Figuras 1 y 2)

Si el MOTOR PARA mientras se está cortando, verifique lo siguiente:

• Motor sin combustible - Verifique el nivel del combustible.



Si el motor diesel se queda sin combustible, se debe sacar el aire fuera del sistema de combustible antes de arrancar el motor. Ver el manual del motor diesel para obtener información detallada sobre la "purga" de aire.

- La falta de agua señala a la Perilla de Seguridad del Agua (1B) que pare el motor. Presione el botón (1B) para reposicionar la perilla y luego vuelva a arrancar el motor.
- La excesiva velocidad de corte producirá el atascamiento del motor.

Si la HOJA DIAMANTADA (2E) PARA mientras se está cortando, verifique:

Si la tensión de la correa de impulsión es inadecuada.

Si el **MOTOR PARA** mientras se está cortando, verifique lo siguiente:

 Levante completamente la hoja fuera del corte; inspeccione minuciosamente la máquina antes de volver a arrancar el motor. Cuando descienda la hoja dentro de un corte parcial, alinee exactamente la hoja con el corte para evitar daños.adecuada.



10

Confíe todos los trabajos de reparación solamente a su concesionario autorizado.



Antes de efectuar cualquier tarea de mantenimiento, SIEMPRE estacione la máquina en una superficie nivelada con el motor APAGADO y la Perilla de Llave del Motor en la posición de APAGADO (OFF).

LIMPIE la máquina después de cada uso.

### LUBRICACION:







**ACEITE DEL MOTOR**: Verifique diariamente. Cambie el aceite y el filtro de aceite después de cada 50 HORAS de operación. Vea el manual del motor para determinar el tipo de aceite a usar. Generalmente se recomienda el 10W30.

- \* Modelos a Gasolina: 10W30 MS, SD, SE o mejor.
- Modelos a Diesel: 10W30 CE ó CD.

Modelo:Capacidad:18W7 pintas20KC4 pintas20H-HDAC3,2 pintas25KC4,2 pintas20D - Hatz5,25 pintas

#### LUBRIQUE LOS COJINETES DIARIAMENTE:

- Ruedas Delanteras
- \* Ruedas Traseras
- Cojinetes del Eje de la Hoja

#### COJINETES DEL EJE DE LA HOJA:

- Lubrique diariamente con una grasa con base en Premio Litio 12, de acuerdo a la consistencia NLG1 GRADO No. 2, sin bisulfuro de molibdeno.
- \* Cuando corte en seco, lubrique diariamente los cojinetes del eje de la hoja 2 ó 3 veces. La grasa proporciona un sello adicional de protección de los cojinetes.

### Reemplazo de los Cojinetes del Eje de la Hoja:

- A. Saque el eje de la hoja de la sierra, sacando los tornillos de cabeza plana (Ilustración 2, Artículo 16).
- B. Saque las bridas internas (Ilustración 2, Artículo 18A) del eje de la hoja, usando una prensa hidráulica o una prensa similar.
- C. Afloje los tornillos de ajuste (Ilustración 2, Artículo 15B) en el cojinete del eje de la hoja.

- D. Saque los cojinetes del eje. Reemplácelos con cojinetes nuevos. Deje aflojados los tornillos de ajuste. Reemplace las bridas internas (Ilustración 2, Artículo 18A).
- E. Instale nuevamente el conjunto de eje de la hoja, reemplazando y apretando los tornillos de cabeza plana.
- F. Alinee el eje de la hoja con el centro de la estructura, a aproximadamente 1-1/4" (32 mm) del costado de la estructura al exterior de la brida interna.
- G. Taladre el eje de la hoja en los sitios de los tornillos de ajuste.
- H. Instale los tornillos de ajuste con Loctite 272 y apriételos.

### **CUIDADO DEL MOTOR**

 Refiérase al manual del motor para obtener información detallada.

### LIMPIEZA DEL FILTRO DE AIRE

- Limpie el filtro de aire diariamente 2 ó 3 veces cuando efectúe cortes en seco. Si está presente, ¡¡NO limpie el Elemento Interno de Seguridad!!
- Refiérase al manual del motor para obtener información detallada.

### TRANSMISION DRIVEMATIC

Una Transmisión Hidrostática ("DRIVEMATIC") (Ilustración 3, Artículo 6) hace que esta unidad sea "AUTO-PROPULSADA". La sierra puede ser empujada simplemente desengranando la transmisión.

#### Mantenimiento de la Transmisión:

- Aceite de Transmisión Hidrostática:
   DIARIAMENTE: Verifique el nivel d
  - DIARIAMENTE: Verifique el nivel de aceite contra el nivel del indicador en el Tanque de Expansión de Aceite (Ilustración 3, Artículo 6A). Las transmisiones son llenadas en fábrica con un aceite que tiene una viscosidad equivalente al SAE20W20, clasificación API SE, CC, CD o mejor. Cuando agregue aceite, use un aceite SAE 30W30, clasificación API SE, CD o mejor. ¡NO use aceites de múltiple viscosidad! Si ocurre una operación errática durante un CLIMA CALUROSO, drene el aceite y recargue con un aceite que tenga una viscosidad SAE 30W30 o SAE 40W40, clasificación API SE, CC, CD o mejor. ¡NO SOBRECARGUE!!
- Afloje la Cadena de Accionamiento de la Transmisión: (Ilustración 3, Artículo 60)
  - La cadena de accionamiento de la transmisión se extenderá durante una operación normal. Ella puede ser ajustada aflojando los cuatro (4) Pernos de unión de la transmisión (Ilustración 3, Artículo 7) y moviendo la transmisión HACIA ARRIBA en las ranuras de la Plataforma de la Transmisión (Ilustración 3, Artículo 1).
- Ruedas de Transmisión de Fricción: (Ilustración 3, Artículo 58)

Si las ruedas de transmisión de fricción NO engranan las ruedas traseras con suficiente presión, puede ocurrir el deslizamiento de las ruedas traseras. Para corregir esta situación, alargue la Unión del Engranaje (Ilustración 3, Artículo 72) aflojando los dos (2) Pernos de ajuste de la unión (Ilustración 3, Artículo 73). Alargue las barras de unión y vuelva a apretar los pernos.

 Aleta de Enfriamiento de la Transmisión Hidrostática: (Ilustración 7, Artículo 6)

NO permita que las aletas de enfriamiento de la transmisión sean cubiertas o taponadas con polvo o suciedad. ¡ESTO NO PERMITIRA EL ENFRIAMIENTO APROPIADO EN EL ACEITE DE LA TRANSMISION!

#### **BARRA PARA LEVANTAMIENTO**

Una Barra para Levantamiento (3B) convencional es un artículo instalado en fábrica en todos los modelos. Es instalada para alcanzar un óptimo balance cuando se efectúen levantamientos. Note la grapa usada (Ilustración 1, Artículo 8) con un motor dado.



ADVERTENCIA: ¡Verifique que los pernos de montaje de la Barra para Levantamiento (3B) estén apropiadamente apretados [torque de 35 libras-pie (47 N-m)] a la estructura y a la cubierta! Verifique que la barra para

levantamiento y la grapa estén montados en la posición apropiada, de manera que la sierra NO se voltee hacia adelante o hacia atrás cuando es levantada. Verifique que los pernos de levantamiento estén apretados (Ilustración 1, Artículo 78) apropiadamente [torque de 70 libras-pie (95 N-m)].

#### MARCADOR DE HORAS

Un Marcador de Horas (1G) es un artículo instalado en fábrica en todos los modelos a gasolina y a diesel. El Marcador de Horas (1G) funcionará continuamente con la Perilla de Llave (1E) en la posición de encendido (ON).

### CADENA DE ACCIONAMIENTO Y PIÑONES

 Verifique el desgaste y el desafloje. Ajuste de acuerdo a las necesidades.



¡No apriete en exceso la Cadena de Accionamiento! El ajuste correcto permite un poco de holgura.



Guarde en un lugar seguro fuera del alcance de los niños. Saque todas las herramientas y llaves de ajuste. Guarde la hoja diamantada (2E) en un lugar seguro de manera que no pueda ser dañada. 11

### TENSIÓN DE LA CORREA TRAPEZOIDAL DEL EJE DE LA HOJA

(Ver Las Figura 1)

Esta sierra está equipada con correas trapezoidales estriadas de alta tensión. Las correas salen de fábrica correctamente tensadas, pero después de unas pocas horas de funcionamiento se estirarán y soltarán.

### Para Tensar Las Correas Trapezoidales:

- Girar el interruptor de arranque del motor (1I) a la posición de **DESCONECTADO**.
- Con una llave, soltar los pernos de fijación horizontal en la parte delantera de la máquina.
- Girar en SENTIDO HORARIO cada uno de pernos de tensión vertical [en la parte delantera de la máquina], hasta que las correas trapezoidales estén tensadas.
- Cambiar las correas trapezoidales en juegos completos solamente.



Nunca apriete las correas trapezoidales más del valor de tensión original de fábrica. Las correas trapezoidales sueltas causan el rendimiento deficien te de la sierra y corta duración de las correas.

12

### **AVISO IMPORTANTE**

(Ver Las Figura 2)

- Apriete regularmente las tuercas y los pernos aflojados, especialmente después de varias horas de operación.
- Verifique regularmente la tensión de la Correa en V.
   Vuelva a apretar las Correas en V de acuerdo a las necesidades. Reemplace las Correas en V en forma de conjuntos completos solamente.
- Saque la Hoja Diamantada (2E) para su almacenamiento.
   Guárdela con cuidado.
- Verifique periódicamente el rociado de agua sobre la Hoja Diamantada (2E).
- Apriete firmemente la Hoja Diamantada (2E) en el Arbol de la Hoja.
- Asegúrese que las caras de contacto de las Bridas (2B y 2F), la Hoja Diamantada (2E) y el Eje de la Hoja (2I) estén limpios.
- USE LA HOJA DIAMANTADA O ABRASIVA CORRECTA. Para obtener el mejor desempeño, póngase en contacto con su distribuidor TARGET para obtener la especificación correcta de la hoja. El uso de la hoja correcta producirá una tremenda diferencia en el costo y en el desempeño de la hoja.
- ANTES DE MONTAR LA HOJA (2E), inspeccione y limpie la Brida y el Arbol del Eje de la Hoja (2F). Inspeccione el área de la Brida y el Arbol del Eje de la Hoja (2F) para verificar si existen daños.
- Monte firmemente la hoja en el Arbol del Eje de la Hoja. La Clavija de Cierre en la Brida Externa de la Hoja (2B) DEBE ir completamente a través de la hoja y dentro del orificio correspondiente en la Brida Interna de la Hoja (2F). Apriete de manera segura la Tuerca de la Brida de la Hoja (2A) [aproximadamente a 50 libras-pie (68 N-m)].



ADVERTENCIA: ¡NO opere sin la protección apropiada de la hoja colocada sobre la hoja!



ADVERTENCIA: ¡NO opere la sierra con el frente del Protector de la Hoja (2H) elevado!



ADVERTENCIA: ¡La exposición de la hoja NO PUEDE exceder de 180 grados cuando está en operación!

 El Apuntador Frontal (3C) y el Apuntador Trasero (3D) deben ser verificados para controlar el alineamiento con la hoja (2E). Ambos apuntadores (3C y 3D) deben estar en línea con la hoja montada sobre el Eje de la Hoja (2I).



FLUJO DE AGUA, de 2-1/2 a 5 galones (10 a 20 litros) de agua por minuto DEBEN fluir sobre la hoja para enfriarla adecuadamente y para obtener la máxima vida útil de la hoja. ¡NO use hojas diamantadas convencionales (húmedas) sin aqua!

 Para CORTES HUMEDOS, asegúrese que los chorros de agua en los Tubos de Agua del Protector de la Hoja están abiertos y que cada costado de la hoja tenga una provisión adecuada de agua. Compruebe la presión y cantidad (flujo) de la fuente de provisión de agua antes de arrancar la sierra. Si la provisión de agua es interrumpida, deje de cortar inmediatamente. La Perilla de Seguridad del Agua (1E) debería apagar la máquina.



NOTA: La Perilla de Seguridad del Agua (1E) no puede detectar una línea de agua atascada porque es sensible a la presión, NO al flujo.

 Para arrancar la sierra para cortes en seco o cuando el agua no está bajo presión, apriete el botón de reposicionamiento en el centro de la Perilla de corte de Seguridad del Agua (1E). Una vez que la Perilla es reposicionada, la presión del agua DEBE estar presente para activar el apagado de seguridad.



NUNCA haga funcionar la bomba de agua sin que fluya agua a través de el la.

- Corte sólo a la profundidad que las especificaciones y las condiciones del trabajo requieran. El corte excesivamente profundo es un derroche-jevítelo! Corte en etapas, con incrementos de 2 pulgadas (50 mm), para obtener mejores resultados.
- Corte en líne recta. Marque claramente la línea de corte de manera que el operador de la sierra pueda seguir la línea sin dificultad. La sierra NO debería ser doblada de lado a lado tratando de forzar el regreso de la hoja a la línea.

### 13

### **VELOCIDAD DEL REGULADOR**

 Es vital que el regulador y el obturador de todos los motores de combustión interna sean ajustados apropiadamente. La velocidad del motor es prefijada en fábrica para la velocidad apropiada de la hoja. Normalmente NO es necesario cambiar este preajuste. Debería ser periódicamente verificado luego que la sierra sea puesta en servicio. Para cambiar el ajuste del regulador, refiérase al manual del motor.



ADVERTENCIA: ¡El exceso de velocidad de la hoja puede producir lesiones personales o la muerte del operador y de las personas presentes en el área circundante!

Para asegurar el ajuste apropiado del regulador, determine la velocidad correcta para el eje de la hoja a partir del siguiente cuadro. Siga el procedimiento de instrucciones del fabricante del motor para ajustar el regulador y el obturador.

### Eje de la Hoja Sin Carga y Revoluciones por Minuto del Motor

	HOJA SIN CARGA	MOTOR
MODELO	RPM	RPM
EC II-18W-14"/20"	2650	3000
EC II-20KC-14"/20"	2620	3600
EC II-20H-14"/20"	2620	3600
EC II-25KC-14"/20"	2620	3600
EC II-20D-14"/20"	2650	3000
EC II-15E-14"/20"	2510	3450
EC II-20H-24"	2008	3600
EC II-20KC-24"	2008	3600
EC II-25KC-24"	2008	3600

### 14

### ÍTEMS EN OPCIÓN Y ACCESORIOS

### BOMBA DE AGUA ELECTRICA (OPCIONAL)

 Una bomba de agua eléctrica opcional está disponible para ser usada en todos los modelos a gasolina y a diesel. LEA y COMPRENDA las instrucciones de operación proporcionadas con la bomba (ITT-JABSCO, Modelo: Serie 18510).



ADVERTENCIA: ¡Debe ser usada para bombear AGUA SOLAMENTE! ¡NO bombee otros materiales!

- Esta bomba NO ES AUTO-CEBADA, de ahí que debe ser cebada antes de ser operada. Se debe mantener suficiente Altura Piezométrica (la fuente de agua por encima de la toma de entrada de la bomba) para que la bomba opere.
- La perilla de apagado/encendido (ON/OFF) de la bomba está localizada en la parte superior de la cubierta. Esta perilla opera la bomba de agua aunque el motor esté encendido o apagado.



ADVERTENCIA: ¡Coloque la perilla en la posición de apagado (OFF) cuando termine, de lo contrario la bomba continuará funcionando hasta que se acabe la batería!

#### CONJUNTO DE PESAS (P/N 176125)

 Un conjunto de pesas está disponible como un accesorio de campo instalado. El conjunto de pesas une el frente de la estructura de la sierra usando dos (2) pernos, arandelas y tuercas. Cada pesa en forma de barra pesa aproximadamente 13 libras (0,9 kg). Dos barras son proporcionadas con cada conjunto [26 libras (11,8 kg) de peso total]. NOTA: Un conjunto de pesas puede ser necesario cuando se corte con un motor Kohler Command u Honda GX620 para evitar que la hoja se eleve fuera del corte.

# CONJUNTO ESPECIAL DE BRIDA EXTERNA DE 5/8" (16 mm) CORTE ANCHO (P/N 176292)

 Un Conjunto Especial de Brida Externa está disponible como un accesorio de campo instalado. La angosta brida externa especial permite que el operador apile hojas hasta un ancho de 5/8" (16 mm). Con la adición de una tuerca angosta especial (Ilustración 2, Artículo 84), el operador puede apilar hojas hasta un ancho de 15/16" (23,8 mm).



ADVERTENCIA: ¡Este conjunto especial de brida externa está destinado para el uso con pilas de 3/8" - 5/8" (10 mm - 16 mm) solamente!

 Si se requieren anchuras de apilamiento de hojas inferiores a 3/8" (10 mm), use el conjunto convencional de brida externa proporcionado con el EC II. El Conjunto Especial de Brida Externa puede ser identificado por la CONTRAMECHA en el "lado de la tuerca" de la brida. El Conjunto Convencional de Brida Externa no tiene CONTRAMECHA. La tuerca angosta especial es para anchuras de apilamiento de hojas entre 5/8" -15/16" (16 mm - 23,9 mm).



ADVERTENCIA: Si no se usan las configuraciones apropiadas de brida y tuerca, SE PRODUCIRAN daños en la hoja.

#### **CONJUNTO DE SOPORTES DE ATADURA** (P/N 167568)

 El conjunto está disponible como un accesorio de campo instalado y consiste de tres (3) anillos para atar, dos de los cuales están instalados en el frente de la estructura y uno debe ser instalado en la parte posterior. Ellos deben ser usados solamente para ASEGURAR la sierra a un camión o a un remolque durante el transporte.



ADVERTENCIA: ¡NO use los soportes de atadura como un mecanismo para levantar la sierra!

Llave Extra para el Eje de la Hoja (P/N 043650)

Conjunto de Iluminación de Lujo (P/N 176124)

15

### **REPARACIONES**

Hacemos todas las reparaciones en los plazos más breves posibles, y a los precios más económicos. (Vea la portada para nuestra dirección y número de teléfono).

16

### PIEZAS DE RECAMBIO


Para un suministro rápido de piezas de recambio y evitar cualquier pérdida de tiempo, en cada pedido es esencial mencionar los datos de la placa de fabricación fijada a la máquina; y el número de pieza que se va a reemplazar.

Las instrucciones de uso y las piezas de recambio presentadas en este documento son solamente para información y no constituyen obligación ninguna. Como parte de nuestra política de mejoramiento de la calidad de nuestros productos, nos reservamos el derecho de hacer cualquiera y todas las modificaciones técnicas sin previo aviso.



¡El fabricante no acepta ninguna responsabilidad por accidentes debidos al uso indebido o modificaciones hechas a la maquina!


### FIGURE 1 – FRAME GROUP



### **FIGURE 1 PARTS LIST**

			(15 L151	IDIAO	DADT	OTV	
DIAG LOC.	PART NO.		DESCRIPTION (*Denotes Metric Item)	DIAG LOC.	PART NO.	QTY. REQ.	DESCRIPTION (*Denotes Metric Item)
*1	176010	1	Cowl Weldment	56	046402	4	Special Flat Washer, 1" OD
*2	139749	6	Capscrew, Hex Hd. M10 x 1.5 x 25mm	57	043280	2	Wheel, 8"
*3	162004	6	Lockwasher, Split M10	*58	167423	1	Pointer, Front
4	043341	1	Depth Control Lock	*59	167564	2	Capscrew, Hex Hd. M12 x 1.75 x 45mm
*5	163688	2	Capscrew, Hex Hd. M6 x 1.0 x 16mm	*60	139742	2	Locknut, Fiber, M12 x 1.75
*6	163689	2	Lockwasher, Split M6	61	043201	1	Cord, Sash (120" Long)
7	176139	2	Handle Bar	62	043203	3	Clamp, Sash Cord
8	139568	2	Handle Grip	63	160196	1 1	Rod, Front Pointer
9	166038	2	Handle Knob, 3/8"-16 UNC	64 64 A	060735	2	Set Collar Assembly, 1/2" (Incl. Item 64A) Set Screw
10	176179	1	Grommet, Fuel Tank	64A 65	163582	2	Wheel, 5"
11	020099	1	Locknut, Flex, 5/8"-18	*66	172306	2	Capscrew, Hex Hd. M12 x 1.75 x 40mm
12 13	020087 043331	1 1	Woodruff Key (ANSI #506)	*67	173010	2	Nut, Thin, M12 x 1.75
14			Hand Wheel Assembly	68	176023	1	Engine Base
15	176175	1	Spacer	*69	176023	2	Engine Base Engine Mounting Bracket
*16	047792	2	Capscrew, Hex Hd. M10 x 1.5 x 30mm	70			
17	043321	1 1	Flanged Bearing, 5/8" Bore	*71	139749	6	Capscrew, Hex Hd. M10 x 1.5 x 25mm
*18	139748	<u>:</u>	Locknut, Fiber, M10 x 1.5	*72	162004	6	Lockwasher, Split, M10
19	176174	1	Feed Screw	*73	139741	4	Capscrew, Hex Hd. M12 x 1.75 x 30mm
20	043301	i	Feed Screw Cover	*74	173042	4	Washer, Flat, M12
20A	049924	$\begin{bmatrix} 1 \\ 1 \end{bmatrix}$	Grease Fitting, 90°	*75	139742	4	Locknut, Fiber, M12 x 1.75
20/ (	0-1002-1		Crease r ming, 50	*76	167439	1	Set Screw, Sq Hd. M12 x 1.75 x 100mm
	470407		Olavia Dia 4/01 v 0 5/01	77	176082	1	Lift Bail
21	176137	1	Clevis Pin, 1/2" x 2-5/8"	*78	139741	2	Capscrew, Hex Hd. M12 x 1.75 x 30mm
22	020616	1	Cotter Pin, 1/8" x 1-1/2"	*79	173042	2	Washer, Flat, M12
23 *24	176097	1	Front Axle Weldment	*80	139742	2	Locknut, Fiber, M12 x 1.75
*25	139749 176222	1 1	Capscrew, Hex Hd. M10 x 1.5 x 25mm	81	176086	1	Brace, Lift Bail (Short)
26	043250	2	Nut, M10 x 1.5 Wheel, 6"		176084	1	Brace, Lift Bail (Long) (Wisc. & Hatz only)
27	048078	4	Set Collar Assembly, 1" (Incl. Item 27A)	*82	167558	1	Capscrew, Hex Hd. M12 x 1.75 x 45mm
27A		4	Set Screw	*83	139742	1	Locknut, Fiber, M12 x 1.75
28	046402	2	Special Flat Washer, 1" ID	*84	139744	1	Capscrew, Hex Hd. M10 x 1.5 x 20mm
29	176025	2	Pivot Block	*85	162004	1	Lockwasher, Split, M10
29A	041175	2	Grease Zerk	*86	139766	1	Capscrew, Hex Hd. M10 x 1.5 x 45mm
*30	176200	<del>-</del>	Capscrew, Hex Hd. M10 x 1.5 x 60mm	*87	139750	1	Nut, Hex, M10 x 1.5
*31	162004	4	Lockwasher, Split, M10	*88	139748	1	Locknut, Fiber, M10 x 1.5
*32	176077	i	Frame Weldment	89	043650	1	Wrench
33	164839	1	Sheave Guard	90	047091	1	Pointer, Rear
*34	197227	2	Capscrew, Hex Hd. M8 x 1.25 x 20mm	*91	164968	1 1	Capscrew, Hex Hd. M10 x 1.5 x 50mm
*35	020785	2	Lockwasher, Split, M8	*92 93	162004 176093	1 1	Lockwasher, Split, M10
36	167387	1	Shaft Guard Shaft Guard	93	170093	1	Fuel Tank, 2.5 Gallons (Incl. Item 93A)
*37	167553	2	Capscrew, Hex Hd. M8 x 1.25 x 100mm	93A		1	Cap, Fuel Tank
*38	173019	2	Lockwasher, M8 (External Tooth)	93A 94	174028	8	Foam Stripping
*39	167433	1	Belt Guard Mounting Clip	95	176050	1 1	Bracket, Fuel Tank
*40	139744	1	Capscrew, Hex Hd. M10 x 1.5 x 20mm	*96	197227	2	Capscrew, Hex Hd. M8 x 1.25 x 20mm
*41	162004	1	Lockwasher, Split, M10	*97	173059	2	Washer, Flat, M8
42	176056	1	Short Belt Guard Ass'y (Honda & Kohler)	*98	139738	2	Locknut, Fiber, M8 x 1.25
* 4.0	176064	1 1	Tall Belt Guard Ass'y (Wisc. & Hatz)	*99	139753	2	Capscrew, Hex Hd. M8 x 1.25 x 30mm
*43	139761	3	Capscrew, Hex Hd. M6 x 1.0 x 20mm	*100	173059	2	Washer, Flat, M8
			(For Short Guard Only)	*101	167555	2	U-Nut, M8 x 1.25
	139761	2	Capscrew, Hex Hd. M6 x 1.0 x 20mm				,
*44	400000		(For Tall Guard Only)				DECALS (NOT SHOWN)
*44	163689	3	Lockwasher, Split, M6 (Short Gd.)				·
*15	163689	2	Lockwasher, Split, M6 (Tall Gd.)		176186	1	Decal, Operating Instructions
*45	139746	3	Washer, Flat, M6 (Short Gd.)		052130	1	Decal, Target
*46	139746 197227	2 2	Washer, Flat, M6 (Tall Gd.) Capscrew, Hex Hd. M8 x 1.25 x 20mm		176202	2	Decal, Econoline II
*47	020785	$\begin{bmatrix} 2 \\ 2 \end{bmatrix}$	Lockwasher, Split, M8		167952	1	Decal, Transmission Engage
*48	173059	$\begin{bmatrix} 2 \\ 2 \end{bmatrix}$	Washer, Flat, M8		163515	2	Decal, Target With Stripe
49	176032	1 1	RH Transmission Pivot Point		176203	1	Decal, Hour Meter
50	176032		LH Transmission Pivot Point		176223	2	Decal (Caution Keep Shield In Place)
*51	176200		Capscrew, Hex Hd. M10 x 1.5 x 60mm		176226	1	Engine Kill Switch (Wisc TJD Only)
*52	162004	4	Lockwasher, Split, M10		176242	1	Decal, Throttle (20HP Diesel Only)
53	176028	1	Rear Axle Shaft		167129	1	Decal, Diesel (20HP Diesel Only)
54	176025	2	Pivot Block		040570	1	Decal, Grease Bearing Daily
54A	020553	2	Set Screw, Socket Hd. 1/4"-28 x 1/4"		164887	1	Decal, Alignment Adjustment
55	048078	2	Set Collar Assembly, 1" (Incl. Item 55A)		176456	1	Decal, Unleaded Fuel Only
55A		2	Set Screw		167129	1	Decal, Fuel-Diesel
		1 - 1		1			

FIGURE 2 – ENGINE & BLADESHAFT GROUP



DIAG	PART		(13 Li31 (iteliis 1 - 30)	DIAG	PART	QTY	(Rev 0/August2002)
LOC.	NO.			LOC.	NO.		
-			. DESCRIPTION (*Denotes Metric Item)				. DESCRIPTION (*Denotes Metric Item)
1	176291	1	Engine, 18 HP Wisc TJD (18W)	13	048732	1	Thread Protector Sleeve
1A		1	Muffler (18W Only)	14	043101	1	Pulley, 4GR3V4.12-SH (14" / 20")
	183035	1	Engine, 20 HP Hatz Diesel (20 Hatz)		176353	1	Pulley, 4GR3V4.75-Type A1 (24")
	190092	1	Engine, 20 HP Honda (See Note 1)	14A	043065	1	Hub, 1-3/16" Bore (14" / 20")
	196033	1	Engine, 24 HP Honda (24H)		176354	1	Hub, SDS Tapered-1.188" (24")
	176197	1	Engine, 20 HP Kohler Command (20KC)				(Item 14A is NOT included w/ Item 14)
	176196	1	Engine, 25 HP Kohler Command (25KC)	14B	020067	1	Key, 1/4" Sq. x 1-1/4" Lg
2	176224	1 1	Pulley, 4GR3V3.65 w/SS (18W-14"/20")	15	043021	2	Bearing, Bladeshaft (includes 15B)
	176076	1	Pulley, Taper 3.65 4GR3V (20 Hatz-14"/20")	15A	164243	2	Grease Fitting
	176220	11	Pulley, 4GR3V3.00-1.00 w/SS (20H-14"/20")	15B		4	Set Screw
	176229	11	Pulley, 4G3V3.00-1.13 w/SS	16	176136	4	Capscrew, Hex Hd. 7/16"-14 x 2-1/2"
			(20KC-14"/20", 25KC-14"/20")	17	020787	4	Lockwasher, Split, 7/16"
	167889	l 1 l	Pulley, 4GR3V2.65-1.00 w/SS (20H-24")	18	176095	11	Blade Shaft
	167942	$\begin{bmatrix} 1 \\ 1 \end{bmatrix}$	Pulley, 4GR3V2.65-1.13 w/SS	18A	045863	2	Inner Collar-4.50" O.D. (14" / 20")
	107012	'	(20KC-24", 24H-24", 25KC-24")		167187	2	Inner Collar-5.00" O.D. (24")
2A	020540	2	Setscrew, Socket Hd. 1/4"-20 x 1/4"	18B	043054	2	Key, Round End
	020040		(18W, 20H, 20KC & 25KC)	19	043040	1 1	Outer Collar w/ Dowel Pin (14" / 20")
2B	176184	1	Key, 3/8" Sq. x 2-1/4" (18W Only)		167367		Outer Collar w/ Dowel Pin (14 / 20 )
2D				19A	020304		
*2	020071	1 1	Key, 1/4" Sq. x 2-1/4" (20H, 20KC, 24H, 25KC)	-		1	Pin, Dowel, .375" Dia x 1.50" Long
*3	167558	4	Capscrew, Hex Hd. M12 x 1.75 x 45mm	20	020017	1	Nut, Hex, 1.00-14UNF (LH)
	400705	١.١	(18W Only)	21	020819	1	Fitting, 3/8NPT x 3/8 Barb
*	139765	4	Capscrew, Hex Hd. M10 x 1.5 x 40mm				(18W, 20KC, 25 KC)
1. 1		1.1	(20 Hatz Only)		161176	1	Fitting, 90° 14NPT x 3/8 Barb (20Hatz)
*	139766	4	Capscrew, Hex Hd. M10 x 1.5 x 45mm	*21A	167138	l 1 l	Fitting, M14 x 1.5 x 1/4NPT (20Hatz)
			(20H, 20KC & 25KC Only)	22	020049	l 1 l	Clamp, Hose
*4	173014	4	Washer, Flat, M10 (20H Only)	23	167308	l 1 l	Hose Assy, Oil Drain, 10" Lg
*5	139742	4	Locknut, Fiber, M12 x 1.75 (18W Only)				(18W, 20KC, 25KC)
*	139748	4	Locknut, Fiber, M10 x 1.5		167304	11	Hose Assy, Oil, Drain 12" Lg (20Hatz)
			(20 Hatz, 20H, 20KC & 25KC Only)	24	167306	$\lfloor \frac{1}{1} \rfloor$	Cap, Blanking
6	176286	1	Electric Motor, 15 HP Leeson (15L)	25	167622		Nut, Tube
7	176290	1	Pulley, 4G3V14L - 1 w/ SS (15L)	26	020051	$\lfloor \frac{1}{4} \rfloor$	Clamp, Hose (20H Only)
7A	020540	2	Setscrew, 1/4"-20 x 1/4" Lg (15L)	27	020051		Hose, 1/2" ID x 12" Lg
7B	020071	1	Key, 1/4" Sq x 2-1/4" Lg (15L)	28	REF	_'	Fuel Tank (See Fig 1, Item 93)
*8	139765	4	Capscrew, Hex Hd. M10 x 1.5 x 40mm	20 29	045639	<del>-</del>	Filter, Fuel (See Note 2)
9	176287	2	Spacer, Motor				,
*10	139748	4	Locknut, Fiber, M10 x 1.5	30	043744	1	Fuel Line, 1/4" x 36" (18W)
11	163858	4	V-Belt, 3VX450 (18W-14"/20")		176243	1	Fuel Line, 5/16" x 45" (20 Hatz)
	045398	4	V-Belt, 3VX475 (20 Hatz-14"/20")		164503	1	Fuel Line, 5/16" x 37"
	172281	4	V-Belt, 3VX400 (20H-14"/20", 24H-24")				(20H, 24H, 20KC & 25KC)
	163857	4	V-Belt, 3VX425				
	100001		(20KC-14"/20", 25KC-14"/20", 15L-14"/20")				
	163857	4	V-Belt, 3VX425				
	103037	+	(20KC-24", 25KC-24")				
	172204	ا ؍ ا	•				
40	172281	4	V-Belt, 3VX400 (20H-24")				
12	020018	1	Nut, Hex, 1.000-14UNF (RH)				

### Notes:


1. P/N 176651 Engine, 20 hp Honda is replaced by P/N 190092 Effective March 2001.

To Retrofit the new Engine (190092) onto an older machine, P/N's 190094 Positive Battery Cable, and P/N 190093 Wiring Harness Must be used.

The Part Number of the Engine can be identified by the ENGINE Serial Number (as shown on the engine): P/N 176651 (Engine S/N 100 0001 - 200 0000) P/N 190092 (Engine S/N 200 0001 & Greater) (Built March 2001)


2. 045639 Filter used for all models except 20H after S/N 200 0000 and except 24H. See Honda dealer for 20H and 24H filters.

FIGURE 2 – ENGINE & BLADESHAFT GROUP




			113 LIST (ILEITIS 31 - 03)	DIAC	DADT	OTV	(08February2000)
DIAG LOC.	Part No.	-	DESCRIPTION (*Denotes Metric Item)	DIAG LOC.		QTY.	DESCRIPTION (*Denotes Metric Item)
			, ,				, ,
31	020049	4	Clamp, Hose	*59	197227	2	Capscrew, Hex Hd. M8 x 1.25 x 20mm
32	164574	1	Grommet, Fuel Valve (20 HATZ Only)	*60	139738	2	Locknut, Fiber, M8 x 1.25
33	164509	1	Valve, Fuel Shut-off (20 HATZ Only)	61	176054	1	Brace, Battery Bracket
34	164504	1	Fuel Line, Return, 1/8" x 30" Lg	*62	197227	1	Capscrew, Hex Hd. M8 x 1.25 x 20mm
			(HATZOnly)	*63	139738	1	Locknut, Fiber, M8 x 1.25
35	045641	2	Clamp, Hose Return (20 HATZ Only)	*64	197227	1	Capscrew, Hex Hd. M8 x 1.25 x 20mm
36	176236	1	Bracket, Ctrl Box Mtg (20 HATZ Only)	*65	020785	1	Lockwasher, Split, M8
*37	139761	4	Capscrew, Hex Hd. M6 x 1.0 x 20mm	66	043725	1	Battery, 12V Lead Acid
*38	163689	4	Lockwasher, Split, M6	67A	REF		(+) Battery Cable (See Wiring Diagram)
39	REF		(20HATZ) Engine Control Box	67B	REF		(-) Battery Cable (See Wiring Diagram)
*40	139761	3	Capscrew, Hex Hd. M6 x 1.0 x 20mm	68	048491	2	Bracket, Battery Hold Down
*41	139745	3	Locknut, Fiber, M6 x 1.0	*69	172507	2	Capscrew, Hex Hd. M8 x 1.25 x 50mm
42	REF		(20H) Voltage Regulator (See Wiring Diagram)	*70	139738	2	Locknut, Fiber, M8 x 1.25
*43	139740	2	Capscrew, Hex Hd. M6 x 1.0 x 25mm	71	176088	1	Rear Shield
			(20H)	*72	167478	4	Capscrew, Hex Hd. M8 x 1.25 x 25mm
*44	163689	2	Lockwasher, Split, M6 (20H Only)	*73	139738	4	Locknut, Fiber, M8 x 1.25
45	REF	<b>—</b>	(20H) Starter Solenoid (See Wiring Diagram)	74	167568	1	Kit, Tie Down Bracket
*46	163688	2	Capscrew, Hex Hd. M6 x 1.0 x 16mm (20H)	75	163977	3	Tiedown, Chain-Loop
*47	139745	2	Locknut, Fiber, M6 x 1.0 (20H Only)	*76	047792	6	Capscrew, Hex Hd. M10 x 1.5 x 30mm
48	045642	1	Fitting, 1/2NPT x GH Swivel w/ Filter	*77	173006	6	Lockwasher, M10 (External)
49	020810	2	Street Elbow, 90° 1/2 NPT	78	176125	1	Kit, Weight Bar
50	020273	1	Pipe Nipple, 1/2-14 x 3 NPT	79	176266	2	Weight Bar (13 lbs.)
*51	139744	2	Capscrew, Hex Hd. M10 x 1.5 x 20mm	80	167444	2	Capscrew, Hex Hd. M12 x 1.75 x 75mm
52	020730	1	Fitting, Pipe Tee, 1/2 NPT	*81	139742	2	Locknut, Fiber, M12 x 1.75
53	020271	1	Pipe Nipple, 1/2-14 x 2 NPT	82	176292	1	Outer Collar Assy - 15/16" Cut (Optional)
54	REF		Water Safety Switch	83	043027	1	Outer Collar - 4.5 OD 15/16" Cut
			(See Wiring Diagram)	83A	020661	1	Pin, Dowel
55	176185	1	Pipe Nipple, 1/2-14 x 17-5/8 NPT	84	020181	1	Nut, Hex Jam Thin, 1-14
56	040261	1	Valve, Ball, 1/2 NPT	85	176105	1	Blade Shaft Assy - Complete
57	176177	1	Water Hose Assembly				· · ·
58	176052	1	Battery Bracket				

### FIGURE 3 – DRIVEMATIC GROUP



DIAG	PART			DIAG	PART	QTY	
LOC.			DESCRIPTION (*Denotes Metric Item)	LOC.	NO.	_	DESCRIPTION (*Denotes Metric Item)
1 2	176035 176032	1   1	Transmission Base Plate RH Transmission Pivot Point	*50 	139748 020136	1 2	Locknut, Fiber, M10 x 1.5① Nut, Hex, 3/8"-16②
3	176032		LH Transmission Pivot Point		020168	1	Nut, Hex Jam, 3/8"-16(3)
*4	047792	2	Capscrew, Hex Hd. M10 x 1.5 x 30mm	51	176180		Bracket, Trans. Idler Arm(1)
*5	139750	2	Nut, Hex, M10 x 1.5	*52	139744		Capscrew, Hex Hd. M10 x 1.5 x 20mm
6	046131	1	Transmission (includes item 6A)	*53	162004		Lockwasher, Split, M10
6A	048326	1 1	Oil Reservoir w/Cap and O-Ring	54	176042		Shaft, Transmission Drive
*7	139752	4	Capscrew, Hex Hd. M10 x 1.5 x 75mm	54A	020062		Key, 3/16" Sq. x 1-1/4"
*8	173014	4	Washer, Flat, M10	55	044161	2	Bearing, Flange, 3/4" Bore
9	139748	4	Locknut, Fiber, M10 x 1.5		041175	2	Fitting, 90° Grease 1/4"-28 Thread
10	020085	3	Key, Woodruff (ANSI #404)	55A			1
11	041370	1	Sprocket w/ Setscrew (#35 12 Teeth)	56	048740	4	Capscrew, Hex Hd. 3/8"-16UNC x 1-1/4"
11A	020540	2	Setscrew, Socket Hd. 1/4"-20 x 1/4"	57	020199	4	Locknut, Fiber, 3/8"-16
11/	020040	_	(incl. w/ Item 11)	58	044181	2	Wheel, Drive
12	176135	1	Pulley, Trans. Drive w/ Setscrew	58A	020643	2	Pin, Roll, 1/4" DIA x 1-1/4"
12A	020540	2	Setscrew, Socket Hd. 1/4"-20 x 1/4"	59	041389	1	Sprocket w/ Setscrew (#35 48 Teeth)
12/	020040	_	(incl. w/ Item 12)	59A	020541	2	Setscrew, Socket Hd. 1/4"-20 x 3/8"
13	163040	2	Plate, Fan Attachment	60	176178	1	Chain, Roller, #35, 60 Pitch
14	163040	1	Flate, Fan Attachment   Fan Blade	61	176046	1	Bracket, Transmission Engagement
15	021423		Capscrew, Hex Hd. 1/4"-20 x 1/2"	*62	176201	4	Capscrew, Socket Bttn Hd.
16	021423	2	Lockwasher, Split, 1/4"			١.	M6 x 1.0 x 16mm
17	020770	1	Capscrew, Hex Hd. 1/4"-20 x 3/4"	*63	163689	4	Lockwasher, Split, M6
*18	172315	3	Capscrew, Hex Hd. M5 x 0.8 x 16mm	64	167791	1	Lever, Trans. Engagement
*19	172316	3	Locknut, Fiber, M5 x 0.8	65	041427	1	Knob, Trans. Lever, 3/8-16UNC
20	176166	1	Lever Weldment, Control	66	167843	1	Pin, Clevis, 1/2" DIA x 1-1/2" Lg
21	020199		Locknut, Fiber, 3/8"-16	67	020766	2	Washer, Flat, 1/2" SAE
*22	173014			68	167035	1	Cotter Pin
*23	167484		Washer, Flat, M10 Screw, Pan Hd. M4 x 0.7 x 20mm	*69	047792	1	Capscrew, Hex Hd. M10 x 1.5 x 30mm
	020739			*70	173014	2	Washer, Flat, M10
24 *25	167485	1   1	Washer, Flat, #10	*71	139748	1	Locknut, Fiber, M10 x 1.5
26	176173		Locknut, Fiber, M4 x 0.7 Quadco Speed Controller	72	176044	2	Linkage, Trans. Engagement
*27	139761	4	Capscrew, Hex Hd. M6 x 1.0 x 20mm	*73	139749	2	Capscrew, Hex Hd. M10 x 1.5 x 25mm
*29	139745	4	Locknut, Fiber, M6 x 1.0	*74	173014	4	Washer, Flat, M10
30	164616		Cable, Speed Control	*75	139748	2	Locknut, Fiber, M10 x 1.5
31	136685	1 2	Nut, Hex Jam, #10-32	*76	167034	1	Capscrew, Hex Hd. M10 x 1.5 x 40mm
32	046591	1	Rod End 10-24	*77	139748	1	Locknut, Fiber, M10 x 1.5
33	176171			78	020786	1	Lockwasher, Split, 3/8" (KC & Wisc Only)
*34	139761	2	Bracket, Trans. Cable Control Capscrew, Hex Hd. M6 x 1.0 x 20mm	79	176225	1	Belt, Accessory, A-51
							(18W, 20HATZ, 20KC & 25KC)
*35 *36	163689 167477		Lockwasher, Split, M6 U-Bolt, M5 x 0.8		046220	1	Belt, Accessory, A-52 (20H)
*37	173047		Washer, Flat, M5		047310	1	Belt, Accessory, 4L510 (15L)
*38	173047	2	Washer, Flat, M5   Locknut, Fiber, M5 x 0.8	$\vdash$		+	T
39	176182	1	Lockflut, Fiber, M5 x 0.6   Idler Arm			1	Transmission Disengagement Spring Group
	176162		Idler Arm(2)	<b>l</b> .		<b>1</b> .	(Not shown on Diagram)
*40	139766		Capscrew, Hex Hd. M10 x 1.5 x 45mm	*	163688	1	Capscrew, Hex Hd. M6 x 1.0 x 16mm
41	167764		Pulley, Idler (Incl. Item 41A)	*	163689	1	Lockwasher, Split M6
*41A	167762		Bushing, M10		163198	1	Spring, Compression, Stainless
*42	173014		Washer, Flat, M10		160465	1	Clamp, Mounting
*43	139748	2	Locknut, Fiber, M10 x 1.5		<del> </del>		<u> </u>
43	139746	1	Spring			<b>.</b>	
45	163259		Clip, Idler Spring	_		SED	
*46	172028		Capscrew, Hex Hd. M8 x 1.5 x 16mm	(T)			onda & Leeson)
*47	020785	1 1	Lockwasher, Split, M8				HP Kohler Command Only)
*48	139744		Capscrew, Hex Hd. M10 x 1.5 x 20mm (1)	(3)	(Wis	c TJ	D Only)
	020377		Capscrew, Hex Hd. 3/8"-16 x 1-1/2" (2)				
	172605		Capscrew, Hex Hd. 3/8"-16 x 1-1/2 (2)  Capscrew, Hex Hd. 3/8"-16 x 1-3/4" (3)				
		4	Washer, Flat, 3/8"(2)				
49	020743	L 4	vvasilei, Flat, 3/0 (2)				




				1	D	Λ	רם	ΓS	ICT	
Г	U	UR	KE.	4		м	<b>T</b>	J	JO I	

DIAG	PART	QTY	•	DIAG	PART	QTY	
LOC.	NO.	REC	DESCRIPTION	LOC.	NO.	REQ	. DESCRIPTION
0		1	Blade Guard Assy – 14" (Use 20")	14	049212	2	Clamp, Water Tube
	190227	1	Blade Guard Assy – <b>20" Blue</b> (3-6 Not Incl)	15	167818	4	Screw, Flat, Slot Hd. M6 x 1.0 x 16mm
	176204	1	Blade Guard Assy – <b>20" Black</b> (3-6 Not Incl)	16	139745	4	Locknut, Fiber, M6 x 1.0
	190222	1	Blade Guard Assy – <b>24" Blue</b> (3-6 Not Incl)	17	163275	1	Guard, Splash
	183015	1	Blade Guard Assy – <b>24" Black</b> (3-6 Not Incl)	18	139761	2	Capscrew, Hex Hd. M6 x 1.0 x 20mm
1	176232	1	Front Guard Weldment – 14" Black	19	139746	2	Washer, Flat, M6
	176153	1	Front Guard Weldment – 20" Blue	20	139745	2	Locknut, Fiber, M6 x 1.0
	176152		Front Guard Weldment – 20" Black	21	043145	1	Spring
	176324	1	Front Guard Weldment – <b>24" Blue</b>	22	139761	2	Capscrew, Hex Hd. M6 x 1.0 x 20mm
	176323	1	Front Guard Weldment – 24" Black	23	172017	4	Nut, Standard Hex, M6 x 1.0
2		1	Rear Guard (Not Available Use Item 0)	24	049154	1	Hinge
3	167531	1	Capscrew, Hex Hd. M12 x 1.75 x 130mm	25	167478	4	Capscrew, Hex Hd, M8 x 1.25 x 25mm
4	020788	1	Lockwasher, Split, 1/2"	26	173059	6	Washer, Flat, M8
5	139751	1	Capscrew, Hex Hd. M12 x 1.75 x 25mm	27	139738	6	Locknut, Fiber, M8 x 1.25
6	020788	1	Lockwasher, Split, 1/2"	28	197228	2	Capscrew, Hex Hd. M8 x 1.25 x 40mm
7	040275	1	Fitting, 3/8" NPT x 3/4" Male Garden Hose			1	24" Blade Guard Items Not Shown:
8	049196	1	Manifold		176402	1	Brace, Blade Guard
9	049206	1	Gasket, Manifold		139749	1	Capscrew, Hex Hd, M10 x 1.5 x 25mm
10	167551	4	Capscrew, Hex Hd. M6 x 1.0 x 40mm		162004	1	Lockwasher, Split, M10
11	139745	4	Locknut, Fiber, M6 x 1.0		173014	1	Washer, Flat, M10
12	167045	2	Water Tube – 14" Guard		166890	1	Capscrew, Hex Hd, M6 x 1.0 x 30mm
	167046	2	Water Tube – 20" Guard		139746	1	Washer, Flat, M6
	176330		Water Tube – 24" Guard		139745	1	Locknut, Fiber, M6 x 1.0
13	020864	2	Plug, 1/8" NPT Socket Hd – Brass				

.13


### FIGURE 5 - DEPTH INDICATOR ASSY



**FIGURE 5 PARTS LIST** 


DIAG	PART	QTY	•			
LOC.	NO.	REQ	. DESCRIPTION (*Denotes Metric Item)			
	176118	1	Depth Indicator Assy (Incl. Items 1-17)			
1	043711	1	Mounting Bracket			
2	030822	2	Pulley and Bearing Assy			
3	032366	2	Locknut, 5/16"-18 (KEPS)			
*4	172390	2	Capscrew, Socket Button Hd.			
			M5 x .8 x 14mm			
*5	172316	2	Locknut, Fiber, M5 x .8			
6	163261	1	Knob, Depth Indicator			
7	043696	1	Bearing, Flanged			
8	043694	1	Pulley, Depth Indicator			
9	020763	2	Washer, Flat, SAE 5/16"			
10	020197	1	Locknut, Fiber, 5/16"-18			
11	043697	1	Cable, 1/8" x 37" Long			
*12	167477	2	Clamp, Cable 6.5mm with M5 Nuts			
13	043702	1	Cable Connecting Arm			
*14	139749	1	Capscrew, Hex Hd. M10 x 1.5 x 25mm			
*15	139748	1	Locknut, Fiber, M10 x 1.5			
16	043757	1	Spring, 8-1/4" LG x 3/8" OD			
17	020619	1	Pin, Cotter, 3/16" x 1-1/2"			

FIGURE 6 - DELUXE LIGHT KIT




### **FIGURE 6 PARTS LIST**

DIAG	PART		
LOC.	NO.	REC	DESCRIPTION (*Denotes Metric Item)
	176124	1	Kit, Deluxe Light Complete
1	0499919	2	Light
2	052120	1	Switch
3	090552	1	Plate, Switch
4	0499925	1	Wire, 16 GA x 36"
5	164370	1	Terminal, Male
6	046440	3	Terminal
*7	197227	2	Capscrew, Hex Hd. M8 x 1.25 x 20mm
*8	139738	2	Locknut, Fiber, M8 x 1.25
9	163758	1	Bar, Support
10	176141	1	Tube, Support
11	166038	1	Knob, 3/8" UNC Thread
*12	139761	4	Capscrew, Hex Hd. M6 x 1.0 x 20mm
*13	163689	4	Lockwasher, Split, M6



DIAG	PART	QTY		DIAG	PART	QTY	•
LOC.	NO.	REC	REQ. DESCRIPTION (*Denotes Metric Item)		NO.	REQ	. DESCRIPTION (*Denotes Metric Item)
	167554	1	Water Pump Kit (Metric/English)	6	020296	2	Fitting, Nipple-Close 3/4" NPT
1	164977	1	Water Pump	7	045643	1	Swivel, with Filter (Incl. Items 7A-7B)
			Replacement Water Pump Parts:	7A	040271	1	Swivel, Without Filter
1A	164083	1	Motor, Impeller, Gasket & Seal	7B	045640	1	Washer, Filter
1B	164580	1	Seal & Gasket Kit	*8	139744	2	Capscrew, Hex Hd. M10 x 1.5 x 20mm
1C	164578	1	Gasket Only		020322	2	Capscrew, Hex Hd. 3/8"-16 x 3/4"
1D	164579	1	Seal Only	*9	162004	2	Lockwasher, Split, M10
1E	164581	1	Impeller Only	*10	173014	2	Washer, Flat, M10
1F	164582	1	Motor Only Motor Only	*11	139761	4	Capscrew, Hex Hd. M6 x 1.0 x 20mm
2	163770	1	Hose Assembly, 3/4" DIA (Inlet)	*12	139746	4	Washer, Flat, M6
3	163769	1	Hose Assembly, 1/2" DIA (Outlet)	*13	139745	4	Locknut, Fiber, M6 x 1.0
4	040273	2	Fitting, 90° Street Elbow, 3/4" NPT	14	020762	4	Washer, Flat, 1/4" SAE
5	163594	1	Bracket, Water Pump				


### FIGURE 8 - WIRING DIAGRAM - WISCONSIN TJD



### **FIGURE 8 PARTS LIST**

				_			
DIAG	PART	QTY		DIAG		QTY	
LOC.	NO.	NO. REQ. DESCRIPTION (*Denotes Metric Item)		LOC.	NO.	REQ	. DESCRIPTION (*Denotes Metric Item)
1	176191	1	Wiring Harness	13	166268	1	Switch, Engine Oil Pressure
2	163779	1	Gauge, Hour Meter	14	176227	1	Wire Lead
3	041317	1	Switch, Engine Kill	15		2	Spark Plug
4	052120	1	Switch, Toggle – Water Pump	16		1	Magneto (Wisc #Y79 Series FMX2B7)
5	167554	1	Water Pump Kit	17		1	Switch, Ignition (Wisc # YC9F)
6		1	Fuse, 10A	18		1	Stator (Wisc # YB-82)
7	163180	1	Battery Cable, (+) Positive, 52" Red	19		1	Rectifier Module (Wisc # YJ-68)
8	043725	1	Battery, 12V Lead Acid	20		1	Regulator Module (Wisc # YJ-60)
9	117133	1	Battery Cable, (-) Negative, 26" Black	21		1	Ammeter (Wisc # YE2)
10	052120	1	Switch, Toggle – Light Kit	22		1	Switch, Start (Wisc # YC10A)
11	176124	1	Deluxe Light Kit	23		1	Starter Assy (Wisc # EEA100)
12	043686	1	Switch, Water Safety	24	164370	2	Connector, Male Push-On


### FIGURE 9 - WIRING DIAGRAM - KOHLER COMMAND



### **FIGURE 9 PARTS LIST**

DIAG LOC.		QTY REC	DESCRIPTION (*Denotes Metric Item)	DIAG LOC.		QTY REQ	. DESCRIPTION (*Denotes Metric Item)
1	176228	1	Wiring Harness	13		1	Engine Wire Harness
2	163779	1	Gauge, Hour Meter	14			Switch, Oil Sentry Shut Down
3	167735	1	Keyswitch (Kohler # 25 099 04)	15		1	Fuel Solenoid Shut Down
4	052120	1	Switch, Toggle – Water Pump	16		1	Starter Assy
5	167554	1	Water Pump Kit	17		1	Rectifier – Regulator
6		1	Fuse, 10A	18		2	Spark Plug
7	163180	1	Battery Cable, (+) Positive, 52" Red	19		1	Flywheel Stator
8	043725	1	Battery, 12V Lead Acid	20	164370	1	Connector, Male Push-On
9	117133	1	Battery Cable, (-) Negative, 26" Black				
10	052120	1	Switch, Toggle – Light Kit	22	176398	1	Neutral Start Switch
11	176124	1	Deluxe Light Kit			1	Neutral Safety Start Switch Trigger
12	043686	1	Switch Water Safety	23	046440	2	Forked Terminal

### FIGURE 10A - WIRING DIAGRAM - HONDA GX620 (Engine S/N 100 0001 - 200 0000)




### FIGURE 104 - PARTS LIST

DIAG LOC.		QTY REQ	. DESCRIPTION (*Denotes Metric Item)	DIAG LOC.	PART NO.	QTY REQ	. DESCRIPTION (*Denotes Metric Item)
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15	176720 163779 163830 052120 167554  190092 043725 163179 052120 176124 043686 176217 164370	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Honda Wiring Harness (For S/N's Shown) Gauge, Hour Meter Keyswitch, (Wisconsin # YC78D) Switch, Toggle – Water Pump Water Pump Kit Fuse, 10A Battery Cable, (+) Positive, 24" Red Battery, 12V Lead Acid Battery Cable, (-) Negative, 40" Black Switch, Toggle – Light Kit Deluxe Light Kit Switch, Water Safety Connector, Male Plug (Hi-Line #SP 228) Connector, Male Push-On	16 17 18 19 20 21 22 23 24 25  28	    	1 1 1 1 1 1 2 1 1 1	Solenoid, Starter Motor, Starter Switch Engine Oil Pressure (Honda#37240-ZG3-E01) Fuel Solenoid Shut Down Transistorized Ignition Unit Engine Stop Diode Spark Plug Charging Coil, 20A (Honda # 31630-ZJ1-801) Engine Wire Harness Rectifier-Regulator, 20A (Honda #31620-ZG5-003) Neutral Safety Switch NO Neutral Start Switch Bracket Forked Terminal

### FIGURE 10B - WIRING DIAGRAM - HONDA GX620 (Effective Engine S/N 200 0001)

(July 18, 2003) (Ref. Wiring Diag. 542182209)




### FIGURE 10B - PARTS LIST

DIAG LOC	PART NO.	QTY. REQ.	I DESCRIPTION I		PART NO.	QTY. REQ.	DESCRIPTION
1	542182208	1	WIRING HARNESS FOR HONDA 20 Hp	11	043686	1	SWITCH, WATER SAFETY
2	163779	1	GAUGE, HOUR METER	12	176398	1	SWITCH, NEUTRAL START
3	163830	1	KEYSWITCH	13	166708	1	RELAY, 12 VDC
4	052120	1	SWITCH, TOGGLE (OPTIONAL)	14		1	SWITCH OIL PRESSURE, HONDA
5	167554	-	WATER PUMP (OPTIONAL)	15		1	STARTER, HONDA
6	190092	1	CABLE, BATTERY, POSITIVE	16		1	FUEL SOLENOID, SHUT DOWN
7	043725	1	BATTERY, 12 VOLT	17		2	COIL, IGNITION, HONDA
8	163179	1	CABLE, BATTERY, NEGATIVE	18		1	ENGINE STOP DIODE, HONDA
9	052120	1	SWITCH, TOGGLE (WITH LIGHT KIT)	19		1	REGULATOR, HONDA
10	176124	1	DELUXE LIGHT KIT (OPTIONAL)	20		1	CHARGING COIL, 20A, HONDA

### FIGURE 10C - WIRING DIAGRAM - HONDA GX670

(Rev 07August2002)



WIRING DIAGRAM FOR ECONOLINE II WITH 24 HP HONDA ENGINE

ITEN	A PART NO	QTY	DESCRIPTION
1	182178	1	WIRING HARNESS FOR HONDA 24 Hp
2		1	WIRING HARNESS, HONDA ENGINE
3	163179	1	CABLE, BATTERY, NEGATIVE
4	163180	1	CABLE, BATTERY, POSITIVE
5		1	STARTER, HONDA
6	176398	1	SWITCH, NEUTRAL SAFETY
7	052120	1	SWITCH, TOGGLE
8	043686	1	SWITCH, WATER SAFETY
9		1	REGULATOR, HONDA
10		2	COIL, IGNITION, HONDA
11	163779	1	GAUGE, HOUR METER
12	177920	1	SWITCH, IGNITION
13	043725	1	BATTERY, 12 VOLT
14		1	OIL LEVEL, HONDA
15	167554	-	WATER PUMP (OPTIONAL)


# FIGURE 11A – WIRING DIAGRAM – HATZ (Units Before Serial Number 244690)

(EC2FIG11.CDR)

REFER TO HATZ DRAWING NUMBER 039 046 01.372 TO CONFIRM HATZ PART NUMBERS SHOWN IN THIS FIGURE.

PART OF 176241 WIRING HARNESS
WIRING SUPPLIED ON ENGINE
(BLACK UNLESS OTHERWISE SPECIFIED)


ENGINE CONTROL COMPONENTS INSTALLED AT HATZ ENGINE NOTE: ENGINE HAS A DUCATI



### **FIGURE 11A PARTS LIST**

DIAG	PART	QTY	•	DIAG	PART	QTY.	
LOC.	NO.	REC	. DESCRIPTION (*Denotes Metric Item)	LOC.	NO.	REQ	. DESCRIPTION (*Denotes Metric Item)
1	176241	1	Hatz Diesel Wiring Harness	17			Relay, 12V (Hatz # 502 777 01)
2	163779	1	Gauge, Hour Meter	18			Alternator (Hatz # 502 836 00)
3			Switch, Ignition (Hatz # 502 765 01)	19			Diode – Complete (Hatz # 010 902 01)
4	052120		Switch, Toggle – Water Pump	20			Diode – Complete (Hatz # 011 501 01)
5	167554		Water Pump Kit	21			Wire – #2 To Lamp (Hatz # 010 321 00)
6			Fuse, 10A	22			Wire – Lamp To Switch (Hatz # 010 976 00)
7	117132		Battery Cable, (+) Positive, 30" Red	23			Wire – #2 & #0 To Relay(Hatz # 008 528 01)
8	043725		Battery, 12V Lead Acid	24			Diode – Complete (Hatz # 011 787 00)
9	117133		Battery Cable, (-) Negative, 26" Black	25			Wire – Relay (Hatz # 011 786 00.824)
10	052120		Switch, Toggle – Light Kit	26			Wire – Relay To Switch (Hatz # 010 921 00)
11	176124		Deluxe Light Kit	27			Wire – #1 To Switch (Hatz # 010 887 00)
12	043686		Switch, Water Safety	28			Wire – #3 To Relay (Hatz # 010 892 00)
13			Starter Assy (Hatz # 400 008 10)	29			Wire – #5 To #4 Terminal (Hatz # 033 568 00)
14			Voltage Regulator (Hatz # 502 838 10)	30	177056		Terminal, Female
15			Indicator Lamp, Battery (Hatz # 501 765 00)	31	164370		Terminal, Male
15A			Bulb, Lamp, 12V-2 (Hatz # 400 097 00)	33	176398		Neutral Safety Switch
16			Terminal (Hatz # 501 607 00)			1	Neutral Safety Switch

# FIGURE 11B – WIRING DIAGRAM – HATZ (Effective w/ Serial Number 244690)



### **FIGURE 11B PARTS LIST**

DIAG	PART	QTY	•	DIAG	PART	QTY	
LOC.	NO.	REQ	. DESCRIPTION	LOC.	NO.	REQ	. DESCRIPTION
1	176241	1	Hatz Diesel Wiring Harness	18		1	Alternator (Hatz # 502 836 00)
2	163779	1	Gauge, Hour Meter	19			
3			Switch, Ignition (Hatz # 502 765 01)	20			
4	052120	1	Switch, Toggle – Water Pump	21			
5	167554	1	Water Pump Kit	22			
6			Fuse, 10A	23		1	Stop Solenoid (Hatz # 0011 864 02)
7	117132	1	Battery Cable, (+) Positive, 30" Red	24		1	Stop Solenoid (Hatz # Y2)
8	043725	1	Battery, 12V Lead Acid	25		1	Time Delay Relay (Hatz # K4)
9	117133	1	Battery Cable, (-) Negative, 26" Black	26		3	Diode IN4007 (Hatz#V2)
10	052120	1	Switch, Toggle Light Kit	27		3	Diode IN4007 (Hatz#V1)
11	176124	1	Deluxe Light Kit	28		2	Terminal Strip (Hatz # X2)
12	043686	1	Switch, Water Safety	29		1	Capacitor (Hatz # C1)
13		1	Starter Assy (Hatz # 400 008 10)	30	176259	2	Connector, Wire
14		1	Voltage Regulator (Hatz # 502 838 10)	31	164370	2	Connector, Wire, Male
15		1	Indicator Lamp, Battery (Hatz # 501 765 00)	32			
15A		1	Bulb, Lamp, 12V-2 (Hatz # 400 097 00)	33	176398		Neutral Safety Switch
16		1	Terminal (Hatz # 501 607 00)			1	Neutral Safety Switch
17		1	Relay, 12V (Hatz # 502 777 Ó1)				

Target Corporate Office					
Customer Service	800-288-5040				
CORP. OFFICE	913-928-1000				
CUST. SERVICE FAX	800-825-0028				
CORP. OFFICE FAX	913-438-7951				
CUST. SERVICE, INT'L	913-928-1300				
INT'L. E-MAIL	RCOATS@DB-INC.COM				
Target Latin America, Mexico, Caribbean,					

## Target Latin America, Mexico, Caribbean, Central and South America

 17400 West 119th Street

 Olathe, Kansas 66061

 Phone
 913-928-1255

 FAX
 913-438-7938

 E-mail
 hleon@db-inc.com

### **Target Canada**

#### **Target Hong Kong, China**

### Target Japan, Korea, Taiwan

1803-36 Oyama-Machi Machida-Shi, Tokyo 194-0212 Japan Phone

1 110116	0172-131-0212
FAX	8142-798-7515
E-mail	fwnh9794@mb.infoweb.ne.jp

### Target Australia, New Zealand/Dembicon Pty. Ltd

29 Kinkaid Avenue

North Plympton, Adelaide SA 5037

Australia

 Phone
 61-83751000

 FAX
 61-83710990

 E-mail
 enquiries@dembicon.com.au

 Internet
 www.dembicon.com.au

# Target Brazil Pix Do Brasil

Rua José de Oliveira Coutinho São Paulo, Brazil CEP 01144-020

 Phone
 55 11 3611-8383

 FAX
 55 11 3619-3022

 E-mail
 pixbrasil@uol.com.br

# Target Singapore, Thailand, Vietnam, Malaysia, Indonesia

 Phone
 65-9628-6175

 FAX
 65-234-2896

 e-mail
 reeh@singnet.com.sg

# European Headquarters DB Construction Business Group

Avenue Du Pont De Luttre, 74 1190 Brussels, Belgium

Phone (32-2) 348-3669 FAX (32-2) 348-3136 Internet www.diamant-boart.com

Target Internet..... www.targetblue.com



81/2-707-0212

### **WARNING**



The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

